



# **GL501M Series @Track Air Interface Protocol**

## **EGPRS/LTE Cat-M1/LTE Cat-NB1/GNSS Tracker**

QSZTRACGL501MAN0114

Version: 1.14

*International Telematics Solutions Innovator*

[www.queclink.com](http://www.queclink.com)

<b>Document Title</b>	GL501M Series @Track Air Interface Protocol
<b>Version</b>	1.14
<b>Date</b>	2020-01-09
<b>Status</b>	Released
<b>Document Control ID</b>	QSZTRACGL501MAN0114

## General Notes

Queclink offers this information as a service to its customers, to support application and engineering efforts that use the products designed by Queclink. The information provided is based upon requirements specifically provided to Queclink by the customers. Queclink has not undertaken any independent search for additional relevant information, including any information that may be in the customer's possession. Furthermore, system validation of this product designed by Queclink within a larger electronic system remains the responsibility of the customer or the customer's system integrator. All specifications supplied herein are subject to change.

## Copyright

This document contains proprietary technical information which is the property of Queclink. Copying of this document, distribution to others, or using or communication of the contents thereof is forbidden without express authority. Offenders are liable to the payment of damages. All rights are reserved in the event of a patent grant or the registration of a utility model or design. All specifications supplied herein are subject to change without notice at any time.

**Copyright © Queclink Wireless Solutions Co., Ltd. 2020**

## Contents

0. Revision History .....	1
1. Overview .....	3
1.1. Scope .....	3
1.2. Terms and Abbreviations .....	3
2. System Architecture .....	4
3. Message Description .....	5
3.1. Message Format .....	5
3.2. Command and Acknowledgement .....	6
3.2.1. Server Connection .....	6
3.2.1.1. Bearer Setting Information .....	6
3.2.1.2. Backend Server Registration Information .....	8
3.2.1.3. Quick Start Setting .....	11
3.2.2. Device Configuration .....	12
3.2.2.1. Global Configuration .....	12
3.2.2.2. Auto Unlock PIN .....	16
3.2.2.3. Software Protocol Watchdog .....	17
3.2.2.4. Time Adjustment .....	19
3.2.2.5. Non-movement Detection .....	20
3.2.2.6. Preserve Device Special Logical State .....	21
3.2.3. Alarm Settings .....	23
3.2.3.1. Geo-fence Information .....	23
3.2.3.2. Temperature Alarm .....	24
3.2.3.3. Light Sensor Alarm .....	25
3.2.3.4. Light Tamper Alarm .....	27
3.2.4. Bluetooth Setting .....	28
3.2.4.1. Bluetooth Setting .....	28
3.2.4.2. Bluetooth Accessory Setting .....	29
3.2.5. Other Settings .....	33
3.2.5.1. Real Time Operation .....	33
3.2.5.2. White Number List Configuration .....	35
3.2.5.3. Settings for SMS with Google Maps Link .....	36
3.2.5.4. Over-the-Air Configuration Update .....	38
3.2.5.5. SMS Position Request .....	39
3.3. Report .....	39
3.3.1. Position Related Report .....	39
3.3.1.1. General Position Report .....	39
3.3.2. Device Information Report .....	44
3.3.3. Report for Querying .....	45
3.3.3.1. +RESP:GTALM .....	45
3.3.3.2. +RESP:GTALC .....	46
3.3.3.3. +RESP:GTCID .....	52
3.3.3.4. +RESP:GTCSQ .....	53
3.3.3.5. +RESP:GTVR .....	53

3.3.3.6. +RESP:GTTMZ .....	54
3.3.3.7. +RESP:GTAIF .....	54
3.3.3.8. +RESP:GTALS .....	56
3.3.3.9. +RESP:GTGSV .....	56
3.3.3.10. +RESP:GTATI .....	57
3.3.4. Event Report .....	58
3.3.5. Buffer Report .....	67
3.4. Heartbeat .....	67
3.5. Sever Acknowledgement .....	68
4. HEX Format Message .....	70
4.1. Hex Report Mask .....	70
4.2. Acknowledgement +ACK .....	74
4.3. Location Report +RSP .....	76
4.4. Information Report +INF .....	83
4.5. Event Report +EVT .....	84
4.6. Heartbeat Data +HBD .....	94
4.7. Buffer Report in HEX Format .....	95
5. Appendix: Message Index .....	97

## 0. Revision History

Version	Date	Author	Description of Change
1.00	2018-09-21	Johar Xiao	Initial
1.01	2018-10-11	Johar Xiao	1. Add light sensor
1.02	2018-10-16	Johar Xiao	1. Add field <network hold time> in GTBSI. 2. Add field <sensor enable> in GTCFG. 3. Add field <motor vibration time> in GTCFG. 4. Add field <Rest send interval> in GTNMR.
1.03	2018-10-23	Roger Luo	1. Changed field <Network Hold Time> in <b>GTSRI</b> . Move the <Sensor Enable> function from <b>GTCFG</b> to <b>GTNMD</b> . 2. Remove field <Motor Vibration Time> in GTCFG. 3. Add field <Include GPS In PSM> in <b>GTCFG</b> . 4. Add field <Battery Low Percentage> in <b>GTCFG</b> . 5. Add field <Power Off Enable> in <b>GTCFG</b> . 6. Add field <Enable Continuous Mode> in <b>GTLSA</b> . 7. Add field <Temperature Enable> in <b>GTTEM</b> . 8. Add field <Enable Continuous Mode> in <b>GTTEM</b> . 9. Changed field <Mode> in <b>GTTEM</b> . 10. Changed field <Mode> in <b>GTNMD</b> . 11. Add Sub Command " <b>CLM</b> " in <b>GTRTO</b> .
1.04	2018-10-29	Roger Luo	1. Changed the description information of <Mode> in <b>GTNMD</b> . 2. Add field <Power On Type> in +RESP:GTPNA.
1.05	2018-11-02	Roger Luo	1. Changed the default value of <Network Hold Time> in <b>GTSRI</b> .
1.06	2018-11-06	Roger Luo	1. Add field <Motor Vibration Time> in GTCFG. 2. Remove +RESP:GTPDP report.
1.07	2018-12-18	Kerwin Shen	1. Modify the range of <Hour Offset> in AT+GTTMA command.
1.08	2018-01-16	Roger Luo	1. Add field <Battery Type> in GTCFG
1.09	2018-01-24	Roger Luo	Modify AT+GTCFG command.
1.0A	2019-02-20	Roger Luo	1. Add field <Final Wakeup Interval> in GTCFG. 2. Add field <Adjustment Enable> in GTCFG. 3. Add field <Hold Days> in GTCFG.
1.0B	2019-03-15	Sean Guo	1. Modified the length of <Back APN>. 2. Modified the contents of +RESP: GTALC.
1.0C	2019-05-09	Sean Guo	Add a note for bit3 of <Mode> of AT+GTNMD.
1.0D	2019-05-17	Sean Guo	Change the System Architecture picture.
1.0E	2019-07-10	Roger Luo	Add field <Light Level> in +RESP:GTLSA.
1.0F	2019-07-20	Roger Luo	Add field <Report Mode> in GTNMD.

1.10	2019-07-29	Roger Luo	<ol style="list-style-type: none"> <li>1. Add field &lt;Protocol Format&gt; in GTSRI.</li> <li>2. Add field &lt;Protocol Format&gt; in GTQSS.</li> <li>3. Add command GTHRM.</li> </ol>
1.11	2019-08-20	Roger Luo	<ol style="list-style-type: none"> <li>1. Update the GTBSI configuration parameter name.</li> <li>2. Add Report +RESP:GTBTC and +RESP:GTSTC.</li> <li>3. Changed field &lt;Event Mask&gt; in GTCFG.</li> </ol>
1.12	2019-10-08	Roger Luo	<ol style="list-style-type: none"> <li>1. Added the “UDP with fixed local port mode” and “Backup server supported TCP long-connection mode” in &lt;Report Mode&gt; of AT+GTSRI.</li> <li>2. Added “GSV” in &lt;Sub Command&gt; of AT+GTRTO.</li> <li>3. Added +RESP:GTGSV report.</li> </ol>
1.13	2019-11-19	Roger Luo	<ol style="list-style-type: none"> <li>1. Added Bluetooth Setting.</li> <li>2. Added field &lt;ERI Mask&gt; in GTCFG.</li> <li>2. Added Report +RESP:GTBAA and +RESP:GTERI.</li> </ol>
1.14	2020-01-09	Sean Guo	<ol style="list-style-type: none"> <li>1. Adjusted the sequence of fields in &lt;Sub Command&gt; of AT+GTRTO; Read field added &lt;AT Command&gt;, &lt;Configuration Mask&gt; and &lt;ATI Mask&gt;.</li> <li>2. Added B, C, D and 1C to the parameter &lt;Sub Command&gt; in the AT+GTRTO command.</li> <li>3. Added +RESP:GTALM, +RESP:GTTMZ, ,+RESP:GTALL,+RESP:GTAIF, and +RESP:GTATI reports.</li> <li>4. Modified &lt;Network Mode&gt; in AT+GTBSI. “GSM first” is added.</li> <li>5. Changed the Geo-fence ID range from 5 to 20.</li> <li>6. Modified parameter &lt;Fix Type&gt; in +RESP:GTGSM.</li> <li>7. Changed the name from &lt;Power off Enable&gt; to &lt;Function Key Mode&gt; and added &lt;SOS Report Mode&gt; and &lt;Location Request Mask&gt; in AT+GTCFG.</li> <li>8. Added +RESP:GTLBC ,+RESP:GTSOS report,</li> <li>9. Added GT+GTGLM report.</li> </ol>

## 1. Overview

### 1.1. Scope

The @Track Air Interface Protocol, a digital communication interface based on printable ASCII characters over SMS or wireless network, is used for all communications between the backend server and the terminal. The backend server sends a command to the terminal and then the terminal confirms with an acknowledgement message.

The purpose of this document is to describe how to build the backend server based on the @Track Air Interface Protocol.

### 1.2. Terms and Abbreviations

Table 1 Terms and Abbreviations

Abbreviation	Description
APN	Access Point Name
ASCII	American National Standard Code for Information Interchange
LTE	Long Term Evolution
HDOP	Horizontal Dilution of Precision
ICCID	Integrated Circuit Card Identity
IP	Internet Protocol
SMS	Short Message Service
TCP	Transmission Control Protocol
UDP	User Datagram Protocol
UTC	Coordinated Universal Time

## 2. System Architecture




Figure 1 System Architecture

The backend server needs to be accessible to multiple terminals and should have the following abilities:

- ✧ The backend server should be able to access the internet and listen for the connection requests originating from the terminals.
- ✧ The backend server should be able to support TCP or UDP connection with the terminal. It should be able to receive data from the terminal and send data to the terminal.
- ✧ The backend server should be able to receive and send SMS.



### 3. Message Description

#### 3.1. Message Format

All the @Track Air Interface Protocol messages are composed of printable ASCII characters. Message formats are shown in the table below:

Message Format	Message Type
AT+GTXXX=<parameter1>,<parameter2>,... \$	Command
+ACK:GTXXX, <parameter1>,<parameter2>,... \$	Acknowledgement
+RESP:GTXXX,<parameter1>,<parameter2>,...\$	Report

The entire message string ends with the character '\$'.

The characters 'XXX' allow the identification of the difference between messages.

The "<parameter1>,<parameter2>,..." carries the message's parameters. The number of parameters is different in different messages. The ASCII character "," is used to separate the neighbouring parameter characters. The parameter string may contain the following ASCII characters: '0'-'9', 'a'-'z', and 'A'-'Z'.

Detailed descriptions of each message format are available in the corresponding message sections.

By sending Commands to the terminal, the backend server can either configure and query the parameters of the terminal or control the terminal to perform specific actions. When the terminal receives Commands over the air, it will reply with a corresponding Acknowledgement message.

The device can send other Reports to the server by configuring related parameters. Please see the following figure:




Figure 2 @Track Protocol Message Flow

When the device receives commands over the air, it supports several commands in one SMS or network packet without separation symbol between adjacent commands. Make sure the total

size of the several commands is no longer than 160 bytes if the commands are sent via SMS. Here is an example of sending two commands in one SMS.

```
AT+GTBSI=gl500m,,,,,,,,0,0,FFFF$AT+GTGEO=gl500m,0,3,101.412248,21.187891,1000,600,,,,,,,,0
008$
```

There are two commands (**AT+GTBSI**, **AT+GTGEO**) in the message above. And the terminal will handle the two commands one by one and it will send the following two acknowledgement messages to the backend server one by one.

```
+ACK:GTBSI,DE0114,352948070074301,,0002,20161005172830,11F0$
+ACK:GTGEO,DE0114,352948070074301,,0,0008,20161005074623,11F1$
```

## 3.2. Command and Acknowledgement

### 3.2.1. Server Connection

#### 3.2.1.1. Bearer Setting Information

The command **AT+GTBSI** is used to set the network parameters.

➤ **AT+GTBSI=**

**Example:**

```
AT+GTBSI=gl500m,,,,,,,,0,0,FFFF$
```

SN	Parameter	Length	Range/Format	Default
1	Password	4 – 20	'0' – '9', 'a' – 'z', 'A' – 'Z'	gl500m
2	LTE APN	<=40	(ASCII)	
3	LTE APN User Name	<=30	(ASCII)	
4	LTE APN Password	<=30	(ASCII)	
5	GPRS APN	<=40	(ASCII)	
6	GPRS APN User Name	<=30	(ASCII)	
7	GPRS APN Password	<=30	(ASCII)	
8	Network Mode/APN Authentication Methods	1	00-33	00
9	LTE Mode	1	0 – 3	2
10	Serial Number	4	(HEX)	
11	Tail Character	1	\$	\$

- ✧ <Password>: The valid characters for the password include '0' – '9', 'a' – 'z', and 'A' – 'Z'. The default value is "gl500m".
- ✧ <LTE APN>: The LTE access point name (APN).
- ✧ <LTE APN User Name>: The LTE APN user name. If the parameter field is empty, the current value of this parameter will be cleared.
- ✧ <LTE APN Password>: The LTE APN Password. If the parameter field is empty, the current value of this parameter will be cleared.
- ✧ <GPRS APN>: The GPRS access point name (APN). If the <LTE APN> does not work, the <GPRS APN> will be used.
- ✧ <GPRS APN User Name>: The GPRS APN user name. If the parameter field is empty, the

current value of this parameter will be cleared.

- ✧ **<GPRS APN Password>**: The GPRS APN Password. If the parameter field is empty, the current value of this parameter will be cleared.

**Note:**

If there is only one APN, please use it as LTE APN.

- ✧ **<Network Mode/APN Authentication Methods>**: This field is in hex format. 4 high bits mean APN authentication methods and 4 low bits mean network mode.

Mobile network modes of the device:

- 0: Auto. (LTE & GSM)
- 1: GSM only.
- 2: LTE only.
- 3: GSM First. (LTE & GSM)

Mobile APN authentication methods of the device:

- 0: No authentication
- 1: PAP authentication
- 2: CHAP authentication
- 3: PAP or CHAP authentication

- ✧ **<LTE Mode>**: Select LTE network mode.
  - 0: Cat-M1 & Cat-NB1 (Cat-M1 First)
  - 1: Cat-NB1 & Cat-M1 (Cat-NB1 First)
  - 2: Cat-M1
  - 3: Cat-NB1

**Note:** When <Network Mode> is 1, <LTE Mode> is invalid.

- ✧ **<Serial Number>**: The serial number of the command. It will be included in the ACK message of the command.
- ✧ **<Tail Character>**: A character which indicates the end of the command. And it must be '\$'.

The acknowledgement message of the **AT+GTBSI** command:

➤ **+ACK:GTBSI,**

Example:			
+ACK:GTBSI,DE0114,352948070074301,,0002,20161005172830,11F0\$			
Parameter	Length	Range/Format	Default
Protocol Version	6	XX0000 - XXXFFF, X ∈ {'A' - 'Z', '0' - '9'}	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' - '9' 'a' - 'z' 'A' - 'Z' '-' '_'	
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

- ✧ **<Protocol Version>**: The protocol version that the terminal conforms to. The first two characters represent the device type. As shown in the example, "DE" means GL501M. The middle two characters represent the major version number of the protocol and the last two

characters represent the minor version number of the protocol. And all the version numbers are hex digits. For example, “**0101**” means version 1.01.

- ✧ <Unique ID>: The IMEI of the terminal.
- ✧ <Device Name>: The specified name of the device.
- ✧ <Serial Number>: A serial number which is included in the corresponding command and is used to distinguish which command the ACK message is for.
- ✧ <Send Time>: The local time to send the ACK message.
- ✧ <Count Number>: A self-increasing count number in each acknowledgment message and other messages. It begins from “0000” and increases by 1 for each message. And it rolls back after “FFFF”.
- ✧ <Tail Character>: A character which indicates the end of the command. It must be ‘\$’.

**Note:** Only after both the commands **AT+GTBSI** and **AT+GTSRI** are properly set can the ACK messages and other messages be received by the backend server.

### 3.2.1.2. Backend Server Registration Information

The command **AT+GTSRI** is used to configure the backend server that the terminal reports to and the report mode that defines the communication method between the backend server and the terminal.

#### ➤ AT+GTSRI=

**Example:**

**AT+GTSRI=gl500m,0,,0,,0,,0,0,,0,0,,FFFF\$**

SN	Parameter	Length	Range/Format	Default
1	Password	4 – 20	‘0’ – ‘9’, ‘a’ – ‘z’, ‘A’ – ‘Z’	gl500m
2	Report Mode	1	0 – 7	0
3	Reserved	0		
4	Buffer Mode	1	0 – 2	1
5	Main Server IP/ Domain Name	<=60	(IP/Domain)	
6	Main Server Port	<=5	0 – 65535	0
7	Backup Server IP/ Domain Name	<=60	(IP/Domain)	
8	Backup Server Port	<=5	0 – 65535	0
9	SMS Gateway	<=20		
10	Heartbeat Interval	<=3	0 5 – 360(min)	0
11	SACK Enable	1	0 – 2	0
12	SMS ACK Enable	1	0 1	0
13	PSM Network Hold Time	<=5	0 - 86400 (sec)	0
14	Protocol Format	1	0 1	
15	Reserved	0		
16	Serial Number	4	(HEX)	

17	Tail Character	1	\$	\$
----	----------------	---	----	----

✧ <Report Mode>: Supported report modes are as follows:

- 0: Stop mode.
- 1: TCP short-connection preferred mode. The connection is based on TCP protocol. The terminal connects to the backend server every time it needs to send data and will cut off the connection when the terminal finishes sending data. And if the terminal fails to establish TCP connection with the backend server (including main server and backup server), it will try to send data via SMS.
- 2: TCP short-connection forced mode. The connection is based on TCP protocol. The terminal connects to the backend server every time it needs to send data and will cut off the connection when the terminal finishes sending data. And if the terminal fails to establish TCP connection with the backend server (including main server and backup server), the data will be stored in the BUFFER (if BUFFER function is enabled, please refer to <Enable Buffer>) or discarded (if the BUFFER function is disabled).
- 3: TCP long-connection mode. The connection is based on TCP protocol. The terminal connects to the backend server and maintains the connection by using the heartbeat data. Please note that in this mode the backend server should respond to the heartbeat data from the terminals.
- 4: UDP mode. The terminal will send data to the backend server through the UDP protocol. It supports receiving protocol command via UDP. Make sure the IP address and UDP port of the device can be visited over the internet, which is generally realized by heartbeat package.
- 5: Force on SMS mode. Only SMS is used for data transmission.
- 6: UDP with fixed local port mode. Like the UDP mode, the terminal will send data by using UDP protocol. The difference is the terminal will use a fixed local port rather than a random port to communicate with the server in this mode. Thus the backend server could use the identical port to communicate with all terminals if the backend server and the terminals are all in the same VPN network. The port number the device uses is the same as the port number of the main server.
- 7: Backup server supported TCP long-connection mode. The connection is based on TCP protocol. The terminal connects to the backend server and maintains the connection by using the heartbeat data. The backend server should respond to the heartbeat data from the terminals. If the main server is lost, it will try to connect the backup server. And if the backup server is also lost, it will try to connect the main server again.

✧ <Reserved>: Not used at present. Please keep it empty.

✧ <Buffer Mode>: Enable or disable the BUFFER function. Please refer to Chapter 3.3.5 for details of the BUFFER function.

- 0: Disable the BUFFER function.
- 1: Enable the BUFFER function.
- 2: High priority—Enable the buffer report function. Under this working mode, the device will send all the buffered messages before sending real-time messages.

✧ <Main Server IP/Domain Name>: The IP address or the domain name of the main server.

- ✧ <Main Server Port>: The port of the main server.
- ✧ <Backup Server IP/Domain Name>: The IP address or the domain name of the backup backend server.
- ✧ <Backup Server Port>: The port of the backup server.
- ✧ <SMS Gateway>: Maximum 20 characters (including the optional national code starting with "+"). Short code (for example, 10086) is also supported.
- ✧ <Heartbeat Interval>: The interval for the terminal to send the heartbeat message to the backend server. If it is set to 0, no heartbeat message will be sent.
- ✧ <SACK Enable>: A numeral to indicate whether the backend server should reply with a SACK message to the device.
  - 0: The backend server does not reply with a SACK message after receiving a message from the device.
  - 1: The backend server should reply with a SACK message after receiving a message from the device.
  - 2: The backend server replies with a SACK message when receiving a message from the terminal, but the terminal does not check the serial number of the SACK message.
- ✧ <SMS ACK Enable>: This defines whether the ACK confirmation should be replied via SMS when the command is sent via SMS.
  - 0: The device will send the ACK confirmation according to the configuration of <Report Mode>.
  - 1: The device will send the ACK confirmation via SMS to the phone which sends the command by SMS.
- ✧ <PSM Network Hold Time>: This parameter is used in power saving mode when the <Report Mode> is TCP long-connection mode, UDP mode or Force on SMS. The network of the device will maintain <PSM Network Hold Time> after the message is sent and then the modem will be shut off.
- ✧ <Protocol Format>: This defines the format of the message sent from the device to the backend server. 0 means using the ASCII format, 1 means the HEX format.
- ✧ <Reserved>: Not used at present. Please keep it empty.
- ✧ <Serial Number>: The serial number of the command. It will be included in the ACK message of the command.
- ✧ <Tail Character>: A character to indicate the end of the command. And it must be '\$'.

**Note:** If <Report Mode> is set to 4 (UDP mode), it is recommended to enable SACK or heartbeat mechanism (in this case, <Heartbeat Interval> should not be set to 0). Otherwise the backend server may not be able to send commands to the terminal.

The acknowledgement message of the **AT+GTSRI** command:

➤ **+ACK:GTSRI,**

<b>Example:</b>			
<b>+ACK:GTSRI,DE0114,352948070074301,,0003,20161005172830,11F0\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	

Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

**Note:** Only after both the commands **AT+GTBSI** and **AT+GTSRI** are properly set can the ACK messages and other messages be received by the backend server.

### 3.2.1.3. Quick Start Setting

The command **AT+GTQSS** is used to set the network parameters and backend server information if the length of all its settings is within 160 bytes. Otherwise, use two commands **AT+GTBSI** and **AT+GTSRI** to configure the settings.

#### ➤ **AT+GTQSS=**

Example:				
<b>AT+GTQSS=gl500m,,,,0,,0,,0,,0,0,0,,,FFFF\$</b>				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 – 20	'0' – '9', 'a' – 'z', 'A' – 'Z'	gl500m
2	LTE APN	<=40	(ASCII)	
3	LTE APN User Name	<=30	(ASCII)	
4	LTE APN Password	<=30	(ASCII)	
5	Report Mode	1	0 – 5	0
6	Protocol Format	1	0 1	
7	Buffer Mode	1	0 – 2	1
8	Main Server IP/ Domain Name	<=60	(IP/Domain)	
9	Main Server Port	<=5	0 – 65535	0
10	Backup Server IP/ Domain Name	<=60	(IP/Domain)	
11	Backup Server Port	<=5	0 – 65535	0
12	SMS Gateway	<=20		
13	Heartbeat Interval	<=3	0 5 – 360(min)	0
14	SACK Enable	1	0 – 2	0
15	SMS ACK Enable	1	0 1	0
16	Network Hold Time	<=5	0 – 86400(sec)	300
17	Serial Number	4	(HEX)	
18	Tail Character	1	\$	\$

The acknowledgement message of the **AT+GTQSS** command:

#### ➤ **+ACK:GTQSS,**

Example: +ACK:GTQSS,DE0114,352948070074301,,0001,20100310172830,11F0\$			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' - '9' 'a' - 'z' 'A' - 'Z' '-' '_'	
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.2. Device Configuration

#### 3.2.2.1. Global Configuration

The **AT+GTCFG** command is used to configure the global parameters.

##### ➤ AT+GTCFG=

Example: AT+GTCFG=gl500m,,gl500m,,0823,001F,0,5,00000000000000,0,,0,1,24,1,1,5,0,0000,0,0,10,0,, FFFF\$				
SN	Parameter	Length	Range/Format	Default
1	Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z'	gl500m
2	New Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z'	
3	Device Name	<=20	'0' - '9', 'a' - 'z', 'A' - 'Z', '-', '_'	gl500m
4	Reserved	0		
5	Event Mask	4	0000 - 0FFF	0823
6	Report Item Mask	4	0000 - 003F	001F
7	Mode Selection	1	0 1	
8	Continuous Send Interval	<=4	0 1-1440(min)	5
9	Week Report Selection	14	00000000000000-11111111 111111	10101010101010
10	Start Mode	1	0-2	0
11	Specified Time of Day	4	HHMM	1200
12	Adjustment Enable	1	0-1	0
13	Initial Wakeup Interval	<=2	1 - 4 6 8 12 24	1
14	Final Wakeup Interval	<=2	1 - 4 6 8 12 24	24
15	Hold Days	<=2	1 - 99	1
16	Report frequency	<=3	1 - 100	1
17	GPS Fix Delay	<=2	5 - 60(sec)	5
18	AGPS Mode	1	0 1	0
19	GSM Report	4	0000 - 0007	0



20	Motor Vibration Time	1	0 - 9 (*100ms)	0
21	Reserved	0		
22	Battery Low Percentage	<=2	0 - 30	10
23	Function Key Mode	1	0 - 2	0
24	ERI Mask	8	00000000-FFFFFFFF	00000000
25	SOS Report Mode	1	0 - 2	1
26	Location Request Mask	1	0 2	2
27	Serial Number	4	(HEX)	
28	Tail Character	1	\$	\$

- ✧ <New Password>: It is used to change the current password.
- ✧ <Device Name>: The name of the device. It appears in each message.
- ✧ <Event Mask>: A Hex value to configure which event report can be sent to the backend server. Each bit corresponds to a message. If the bit is set to 1, the corresponding message can be sent to the backend server. Otherwise, the corresponding message cannot be sent to the backend server. Here is the matching between each bit and message.

Bit 0 (0001): **+RESP:GTPNA**

Bit 1 (0002): **+RESP:GTPFA**

Bit 2 (0004): **+RESP:GTBTC**, only GL501MG supports this report.

Bit 3 (0008): **+RESP:GTSTC**, only GL501MG supports this report.

Bit 4 (0010): Reserved

Bit 5 (0020): **+RESP:GTBPL**

Bit 6 (0040): Reserved

Bit 7 (0080): Reserved

Bit 8 (0100): Reserved

Bit 9 (0200): Reserved

Bit 10 (0400): Reserved

Bit 11 (0800): **+RESP:GTPNL**

Bit 12 (1000): Reserved

Bit 13 (2000): Reserved

- ✧ <Report Item Mask>: Bitwise report mask to configure the composition of all the messages. Each bit represents a field in the message. If a bit is set to 1, the corresponding field will be filled if it is included in the message. Otherwise, the field will be empty.

Bit 0 (0001): <Speed>

Bit 1 (0002): <Azimuth>

Bit 2 (0004): <Altitude>

Bit 3 (0008): Cell information, including <MCC>, <MNC>, <LAC>, and <Cell ID>

Bit 4 (0010): <Send Time>

Bit 5 (0020): <Device Name>

Bit 6 (0040): Reserved

- ✧ <Mode Selection>: It configures the working mode of the terminal.

- 0: Power saving mode (PSM). The terminal is in power saving status and report the message **+RESP:GTFRI** periodically according to power saving mode parameters. The connection between the terminal and the server will be maintained for a

period of time according to the setting of *<Network Hold Time>* in **AT+GTSRI**, and then go into deep sleep.

- 1: Continuous mode. The terminal is always active when Report Mode of **AT+GTSRI** is set to 3 or 4 (TCP long-connection mode or UDP mode). This allows the control of the terminal at any time and immediate receipt of ACK information from the terminal. The terminal performs GPS fix and reports the message **+RESP:GTFRI** periodically according to *<Continuous Send interval>*.

Note that if any sensor (GTNMD, GTTEM, GTLSA) is used to switch over the mode of the device, the working mode of the device will be determined by the sensor status and *<Mode Selection>* will become invalid in such circumstance.

- ✧ *<Continuous Send Interval>*: The send interval of message **+RESP:GTFRI** when *<Mode Selection>* is set to 1. The value range is 1-1440 and the unit is minute. If the value is set to 0, the device will not report the message.
- ✧ *<Week Report Selection>*: It configures the report mode for each day in one week. There are a total of seven 2-character combinations. The seven combinations represent seven days of one week respectively. The first two characters represent Sunday, and last two characters represent Saturday.

The first character of each combination defines whether the terminal will report messages to the server on this day of week, and the second character defines whether the message should contain GPS information when the first character is set to 1.

The 14-digit format can be configured as follows.

**Example:** 11000000101011. It means the messages on Sunday and Saturday will contain GPS information, no message will be reported Monday, Tuesday and Wednesday, and messages for Thursday and Friday will not contain GPS information.

- ✧ *<Start Mode>*: It configures how to determine the first wakeup time. The time of next wakeup will be calculated based on the *<Wakeup Hour Interval>*.
  - 0: First wakeup at the time defined by *<Specified Time of Day>*.
  - 1: To get the first wakeup time, add the current time and *<Wakeup Hour Interval>*.
  - 2: The terminal will first wake up at the wake-up time point (calculated by *<Specified Time of Day>* and *<Wakeup Hour Interval>*) nearest to the current time. Wake-up time points are the time that the terminal should wake up at each day. For example, if *<Specified Time of Day>* is 0300 and *<Wakeup Hour Interval>* is 4 hours, then the wake-up time points are 03:00, 07:00, 11:00, 15:00, 19:00, 23:00. If the current time is 15:30, then the nearest wake-up time is 19:00.
- ✧ *<Specified Time of Day>*: It configures the start time for the terminal to wake up (also referred to as first wakeup time herein). The value range of "HH" is "00"-"23". The value range of "MM" is "00"-"59".
- ✧ *<Adjustment Enable>*: Enable/disable the interval adjustment of the wakeup interval.
  - 0: Disable interval adjustment.
  - 1: Enable interval adjustment.
- ✧ *<Initial Wakeup Interval>*: A numeral to specify the initial hour interval for waking up the terminal. The value 24 means the terminal wakes up once per 24 hours. If *<Adjustment Enable>* is disabled, the device will always use this value as its waking up interval.
- ✧ *<Final Wakeup Interval>*: A numeral to specify the final hour interval for waking up the

terminal. The value 24 means the terminal wakes up once per 24 hours. If the *<Adjustment Enable>* is enabled, after the specified time of *<Hold Days>*, the device's waking up interval switches from *<Initial Wakeup Interval>* to *<Final Wakeup Interval>*. And the device's report interval will remain at this value.

- ✧ *<Hold Days>*: The number of days to hold *<Initial Wakeup Interval>* before switching to *<Final Wakeup Interval>*.
- ✧ *<Report Frequency>*: This parameter value multiplied by *<Initial Wakeup Interval>* or *<Final Wakeup Interval>* equals the report frequency (Unit: hour) for the message **+RESP:GTFR1**.

**Note:** If *<Report Frequency>* is set to 2 and *<Initial Wakeup Interval>* or *<Final Wakeup Interval>* is set to 2, the terminal will wake up every 2 hours and report the **+RESP:GTFR1** every 4 hours.

- ✧ *<GPS Fix Delay>*: This value indicates the waiting time after GPS fix succeeds. After GPS fix succeeds, the device will wait for a period of time (specified by *<GPS Fix Delay>*) and then get the result of GPS fix because the position obtained immediately after the GPS fix may not be accurate. (e.g. If *<GPS Fix Delay>* is set to 7, the device will wait 7 seconds after GPS fix and then get the fix result). The range of the parameter value is 5 – 60, and the default value is 5. Unit: second.
- ✧ *<AGPS Mode>*: A numeral to indicate whether to enable AGPS. AGPS is helpful to improve the chance to get GPS position successfully and reduce the time to get GPS position.
  - 0: Disable the AGPS function.
  - 1: Enable the AGPS function.

**Note:** The AGPS uses a URL to download the ephemeris data. Some SIM card operators do not support parsing URL to get the data. Contact with the SIM card provider to see whether URL parsing is supported or not. If not, disable this function. Otherwise, the power consumption of the device will increase. AGPS only increases the speed to get GPS fix. It will not affect the function of GPS.

- ✧ *<GSM Report>*: It controls how or when to report cell information. The message **+RESP:GTGSM** is only sent via TCP short connection even if the report mode is Force on SMS.

The 2 high bits, Bit 14 – 15, represent the GSM report mode.

- 0: Do not allow the cell information report.
- 1: Allow the cell information report after failing to get GPS position if cell information is available.
- 2: Report the message **+RESP:GTGSM** after each successful GPS fix if cell information is available.
- 3: Report the message **+RESP:GTGSM** regardless of getting GPS position is successful or not if cell information is available.

The 2 low bits, bit0 and bit2 are used to configure **+RESP:GTGSM** will be sent after which message.

- Bit 0 for **+RESP:GTRTL**
- Bit 2 for **+RESP:GTFR1 | GTER1**

- ✧ *<Motor Vibration Time>*: Enable/disable motor vibration function during device power on or power off. 0 means to disable the motor vibration. Unit: 100ms.
- ✧ *<ERI Mask>*: If the serial port is connected to peripherals and the mask is not 0x00000000,

the device will send **+RESP:GTERI** instead of **+RESP:GTFRI**. This mask is used to configure whether to report the data from peripherals by **+RESP:GTERI**.

- Bit 0 for reserved.
- Bit 1 for reserved
- Bit 2 for reserved.
- Bit 3 for reserved.
- Bit 8 for <Bluetooth Accessory> field in the report of **+RESP:GTERI**. If it is set to 1, the data block <Bluetooth Accessory> will be displayed.
- ✧ <Battery Low Percentage>: If the battery percentage is lower than the value specified by this parameter, the terminal will report the message **+RESP:GTBPL**.
- ✧ <Function Key Mode>: The working mode for the function key long press operation.
  - 0: The device will not perform any operation when the button is long pressed.
  - 1: The device will power off when the button is long pressed.
  - 2: When the function key is long pressed, SOS event will be triggered.
- ✧ <SOS Report Mode>: A numeral to indicate the way of reporting GPS location for SOS event.
  - 0: Report only the last GPS location immediately after SOS event is triggered.
  - 1: Try to report the current GPS location after SOS event is triggered.
  - 2: Report the last GPS location immediately after SOS event is triggered and then tries to get the current GPS location to report.
- ✧ <Location Request Mask>: Mask to control the location request
  - Bit 0: Reserved.
  - Bit 1: SMS location request.

**Note:** If the device is in power saving mode, the module is turned off also. So it cannot receive and process the “get position” message at this time. It will process the message after the device wakes up.

The acknowledgement message of the **AT+GTCFG** command:

➤ **+ACK:GTCFG,**

Example: <b>+ACK:GTCFG,DE0114,352948070074301,,0004,20161005172830,11F0\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.2.2. Auto Unlock PIN

The **AT+GTPIN** command is used to unlock the SIM automatically.

➤ **AT+GTPIN=**

**Example:****AT+GTPIN=gl500m,0,,,,,,FFFF\$**

SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 – 20	'0' – '9', 'a' – 'z', 'A' – 'Z'	gl500m
2	Auto Unlock PIN	1	0 1	0
3	PIN	4 - 8	'0' – '9'	
4	Reserved	0		
5	Reserved	0		
6	Reserved	0		
7	Reserved	0		
8	Reserved	0		
9	Serial Number	4	(HEX)	
10	Tail Character	1	\$	\$

- ✧ <Auto Unlock PIN>: A numeral to indicate whether to unlock the PIN for the device.
  - 0: Do not unlock PIN automatically.
  - 1: Each time the device powers on, it will detect whether the SIM card is locked with a PIN. If it is locked, the device will auto-unlock the PIN.
- ✧ <PIN>: The PIN code which is used for unlocking PIN automatically. If it is empty, the PIN code saved in the device will be cleared.

The acknowledgment message of the **AT+GTPIN** command:

➤ **+ACK:GTPIN,**

**Example:****+ACK:GTPIN,DE0114,352948070074301,,000E,20161005085505,0027\$**

Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

**3.2.2.3. Software Protocol Watchdog**

The **AT+GTDG** command is used to reboot the device in a time based manner. This helps the device avoid working in an abnormal status for a long time.

➤ **AT+GTDG=**

**Example:****AT+GTDG=gl500m,0,,30,0200,,1,,0,,,,FFFF\$**

SN	Parameter	Length (Byte)	Range/Format	Default
----	-----------	---------------	--------------	---------

1	Password	4 – 20	'0' – '9', 'a' – 'z', 'A' – 'Z'	gl500m
2	Mode	1	0 1	1
3	Reserved	0		
4	Reboot Interval	<=2	1 - 30	7
5	Reboot Time	4	HHMM	0200
6	Reserved	0		
7	Report Before Reboot	1	0 1	1
8	Reserved	0		
9	Unit	1	0 1	0
10	Reserved	0		
11	Reserved	0		
12	Reserved	0		
13	Serial Number	4	(HEX)	
14	Tail Character	1	\$	\$

- ✧ <Mode>: The working mode of the watchdog function.
  - 0: Disable this function.
  - 1: Reboot periodically according to the <Interval> and <Time> settings.
- ✧ <Reboot Interval>: The interval for rebooting the device.
- ✧ <Reboot Time>: The time to perform the reboot operation when the <Interval> condition is met.
- ✧ <Report Before Reboot>: Whether to report the **+RESP:GTD OG** message before reboot. 0 means "Do not report the **+RESP:GTD OG** message before reboot", and 1 means "Report the **+RESP:GTD OG** message before reboot". If this parameter is enabled, the device will obtain a real-time location and send it to the server.
- ✧ <Unit>: The unit of the <Interval> value.
  - 0: Day.
  - 1: Hour.

The acknowledgment message of the **AT+GTD OG** command:

➤ **+ACK:GTD OG,**

Example:			
<b>+ACK:GTD OG,DE0114,352948070074301,,0011,20161005085505,0028\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.2.4. Time Adjustment

The command **AT+GTTMA** is used to adjust local time.

#### ➤ AT+GTTMA=

**Example:**

**AT+GTTMA=gl500m,+,0,0,0,,,,,FFFF\$**

SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 – 20	'0' – '9', 'a' – 'z', 'A' – 'Z'	gl500m
2	Sign	1	+ -	+
3	Hour Offset	<=2	0 - 12	00
4	Minute Offset	<=2	0 - 59	00
5	Daylight Saving	1	0 1	0
6	UTC Time	14	YYYYMMDDHHMMSS	
7	Reserved	0		
8	Reserved	0		
9	Reserved	0		
10	Reserved	0		
11	Serial Number	4	(HEX)	
12	Tail Character	1	\$	\$

- ✧ <Sign>: It indicates the positive or negative offset of the local time from UTC time.
- ✧ <Hour Offset>: The UTC offset in hours.
- ✧ <Minute Offset>: The UTC offset in minutes.
- ✧ <Daylight Saving>: Enable/disable daylight saving time.
  - 0: Disable daylight saving time.
  - 1: Enable daylight saving time.
- ✧ <UTC Time>: UTC time used to adjust the local time.

The acknowledgement message of the **AT+GTTMA** command:

#### ➤ +ACK:GTTMA,

**Example:**

**+ACK:GTTMA,DE0114,352948070074301,,0007,20161005172830,11F0\$**

Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$



### 3.2.2.5. Non-movement Detection

The **AT+GTNMD** command is used to configure the parameters for non-movement detection.

#### ➤ AT+GTNMD=

Example: AT+GTNMD=gl500m,0,0,3,3,2,1440,1,,,,,,,,,FFFF\$				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 – 20	'0' – '9', 'a' – 'z', 'A' – 'Z'	gl500m
2	Sensor Enable	1	0 - 1	0
3	Mode	1	0 - F	0
4	Non-movement Duration	<=3	1 – 200(*15sec)	3
5	Movement Duration	<=2	3 – 50(*100ms)	3
6	Movement Threshold	1	2 – 9	2
7	Rest Send Interval	<=4	5 - 1440(min)	1440
8	Report Mode	1	1 - 3	2
9	Reserved	0		
10	Reserved	0		
11	Reserved	0		
12	Reserved	0		
13	Reserved	0		
14	Reserved	0		
15	Reserved	0		
16	Serial Number	4	(HEX)	
17	Tail Character	1	\$	\$

✧ **<Sensor Enable>**: Enable/disable the sensor function. If the sensor is enabled, and movement is detected, the terminal will enter continuous mode to perform GPS fix and report message.

✧ **<Mode>**: A hex numeral to determine how the function works. Each bit of the hex numeral indicates different actions the device can perform. If a bit is 1, the device will perform the corresponding action as described below.

Bit 0 (1): When it detects non-movement, then enter power saving mode.

Bit 1 (2): Report the message **+RESP:GTNMR** to the backend server when it detects non-movement.

Bit 2 (4): Report the message **+RESP:GTNMR** to the backend server when it detects movement.

Bit 3 (8): Change the GPS fix interval and the **+RESP:GTFRI** report interval to **<Rest Send Interval>** when non-movement is detected.

**Note:** If Bit3 is enabled, Bit0 will become invalid. And the device maintains in continuous mode. If **<Report Mode>** of **AT+GTSRI** is set to 3: TCP Long-connection Mode or 4: UDP Mode, the device will never go to sleep.

✧ **<Non-movement Duration>**: A time parameter to determine whether the device enters



non-movement status. If the motion sensor detects that the device stays in non-movement status for a period of time specified by *<Non-movement Duration>*, the device will be considered to be in non-movement status.

- ✧ *<Movement Duration>*: A time parameter to determine whether the device enters movement status. If the motion sensor detects that the device stays in movement for a period of time specified by *<Movement Duration>*, the device will be considered to be in movement status.
- ✧ *<Movement Threshold>*: The threshold for the motion sensor to determine whether the device is in movement state. The smaller the value is, the easier it will be for the device to be considered to enter the state of movement.
- ✧ *<Rest Send Interval>*: The send interval for the **+RESP:GTFRI** message when the device is in rest state and bit 3 of *<Mode>* is set to 1.
- ✧ *<Report mode>*: A numeral to configure how to report **+RESP:GTNMR** when motion sensor status changes.
  - 1: Report the last fixed position.
  - 2: Report the current position.
  - 3: Report the last fixed position immediately, and then turn on GPS to get the current position and report position information again.

The acknowledgement message of the **AT+GTNMD** command:

➤ **+ACK:GTNMD,**

Example:			
<b>+ACK:GTNMD,DE0114,352948070074301,,0005,20161005172830,11F0\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.2.6. Preserve Device Special Logical State

The command **AT+GTPDS** is used to preserve special logic state of the terminal. Enable the function according to the working mode, and save the logic state according to the value of the *<Mask>*.

➤ **AT+GTPDS=**

Example:				
<b>AT+GTPDS=gl500m,1,00000011,,,,,FFFF\$</b>				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 – 20	'0' – '9' 'a' – 'z' 'A' – 'Z'	gl500m

2	Mode	1	0 - 2	1
3	Mask	8	00000000-FFFFFFFF	00000019
4	Reserved	0		
5	Reserved	0		
6	Reserved	0		
7	Reserved	0		
8	Reserved	0		
9	Reserved	0		
10	Serial Number	4	(HEX)	
11	Tail Character	1	\$	\$

✧ **<Mode>**: The working mode of the **AT+GTPDS** command.

- 0: Disable this function.
- 1: Preserve special logic state of the device according to the value of the **<Mask>**.
- 2: Reset all the special logical states listed in the **<Mask>** after receiving the command, and then preserve special logic state of the device according to the value of the **<Mask>**.

✧ **<Mask>**: Bitwise mask to configure which device states will be preserved.

Each bit represents a state.

- Bit 0: States of GEO
- Bit 1: Reserved
- Bit 2: Reserved
- Bit 3: Information of last known position
- Bit 4: Current device state, including motion state

The acknowledgment message of the **AT+GTPDS** command:

➤ **+ACK:GTPDS,**

Example:			
+ACK:GTPDS,DE0114,352948070074301,,000D,20161005093254,FFFF\$			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	

Tail Character	1	\$	\$
----------------	---	----	----

### 3.2.3. Alarm Settings

#### 3.2.3.1. Geo-fence Information

The command **AT+GTGEO** is used to configure the parameters of Geo-fence. Geo-fence is a virtual perimeter around a geographic area using a location-based service. When the terminal enters or exits the area, a notification is generated. The notification contains information about the location of the terminal and will be sent to the backend server.

##### ➤ AT+GTGEO=

Example: AT+GTGEO=gl500m,0,3,101.412248,21.187891,1000,600,,,,,,,,,0008\$				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 – 20	'0' – '9', 'a' – 'z', 'A' – 'Z'	gl500m
2	GEO ID	1	0 – 19	
3	Mode	1	0 – 3	0
4	Longitude	<=11	(-)XXX.XXXXXX	
5	Latitude	<=10	(-)XX.XXXXXX	
6	Radius	<=7	50 – 6000000(min)	50
7	Reserved	0		
8	Reserved	0		
9	Reserved	0		
10	Reserved	0		
11	Reserved	0		
12	Reserved	0		
13	Reserved	0		
14	Reserved	0		
15	Reserved	0		
16	Serial Number	4	(HEX)	
17	Tail Character	1	\$	\$

- ✧ <GEO ID>: A numeral to identify the Geo-fence.
- ✧ <Mode>: A numeral which indicates when to report the notification to the backend server:
  - 0: Disable the Geo-fence on the specified GEO ID.
  - 1: Reports when entering the Geo-fence.
  - 2: Reports when leaving the Geo-fence.
  - 3: Reports when entering or leaving the Geo-fence.
- ✧ <Longitude>: The longitude of a point which is defined as the centre of the circular Geo-fence region. The format is "(-)xxx.xxxxxx" and the value range is from "-180.000000" to "180.000000". The unit is degree. West longitude is represented as a negative value starting with the minus sign "-" and east longitude is represented as a positive value without "+".

- ✧ <Latitude>: The latitude of a point which is defined as the centre of the circular Geo-fence region. The format is “(-)xx.xxxxxx” and the value range is from “-90.000000” to “90.000000”. The unit is degree. South latitude is represented as a negative value starting with the minus sign “-” and north latitude is represented as a positive value without “+”.
- ✧ <Radius>: The radius of the circular Geo-fence region. The value range is (50-6000000) and the unit is meter.

The acknowledgement message of the **AT+GTGEO** command:

➤ **+ACK:GTGEO,**

Example:			
+ACK:GTGEO,DE0114,352948070074301,,0,0008,20191005172830,11F0\$			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
GEO ID	1	0 – 4	
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.3.2. Temperature Alarm

The **AT+GTTEM** command is used to configure the temperature alarm function of the device. Based on the working mode, the device will report temperature alarm when its temperature is outside or inside a predefined range.

➤ **AT+GTTEM=**

Example:				
AT+GTTEM=gl500m,0,0,0,0,60,300,0,,,,,FFFF\$				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 – 20	'0' – '9', 'a' – 'z', 'A' – 'Z'	gl500m
2	Temperature Enable	1	0 1	0
3	Mode	1	0 – 4	0
4	Min. Temperature	<=3	-20 – 60	0
5	Max. Temperature	<=3	-20 – 60	0
6	Duration	<=4	10 – 3600(sec)	60
7	Send Interval	<=4	0 10 – 3600(sec)	300
8	Enable Continuous Mode	0	0 1	0
9	Reserved	0		
10	Reserved	0		
11	Reserved	0		
12	Reserved	0		

13	Serial Number	4	(HEX)	
14	Tail Character	1	\$	\$

- ✧ **<Temperature Enable>**: Enable/Disable the temperature function. If disabled, the temperature value will be empty in the report.
- ✧ **<Mode>**: A numeral to indicate the working mode of the temperature alarm function.
  - 0: Disable this function.
  - 1: Report the alarm message **+RESP:GTTEM** when the current temperature is lower than the temperature specified by **<Min. Temperature>**.
  - 2: Report the alarm message **+RESP:GTTEM** when the current temperature is higher than the temperature specified by **<Max. Temperature>**.
  - 3: Report the alarm message **+RESP:GTTEM** when the current temperature is inside the temperature range.
  - 4: Report the alarm message **+RESP:GTTEM** when the current temperature is outside the temperature range.
- ✧ **<Min. Temperature>**: The lower limit of the temperature range.
- ✧ **<Max. Temperature>**: The upper limit of the temperature range.
- ✧ **<Duration>**: If the temperature is in the specified temperature range and is maintained for a period of time specified by **<Duration>**, the temperature alarm will be triggered.
- ✧ **<Send Interval>**: If the temperature alarm is triggered, the temperature alarm message will be sent periodically according to **<Send Interval>**. If the **<Send Interval>** is set to 0, the temperature alarm message will be sent only once.
- ✧ **<Enable Continuous Mode>**: If it is enabled and the temperature alarm is triggered, the device enters continuous mode, otherwise it enters power saving mode.

The acknowledgment message of the **AT+GTTEM** command:

➤ **+ACK:GTTEM,**

Example:			
<b>+ACK:GTTEM,DE0114,352948070074301,,000E,20161005093254, 000E\$</b>			
Parameter	Length	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' ' ' ' _ '	
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.3.3. Light Sensor Alarm

The **AT+GTLA** command is used to configure the light sensor alarm function. The two parameters **<Mode>** and **<Sensitivity Threshold>** are combined to determine whether the light sensor alarm event will be triggered.

➤ **AT+GTLSA=****Example:****AT+GTLSA=gl500m,0,5,3,0,0,2,0,,,,,FFFF\$**

SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 – 20	'0' – '9', 'a' – 'z', 'A' – 'Z'	gl500m
2	Mode	1	0 – 2	0
3	Sensitivity Threshold	1	1 - 9	5
4	Duration	<= 2	3 – 30	3
5	Send Interval	<= 3	0 10 – 300(sec)	0
6	End report	1	0 1	0
7	Report Mode	1	1 – 3	2
8	Enable Continuous Mode	0	0 1	0
9	Reserved	0		
10	Reserved	0		
11	Reserved	0		
12	Reserved	0		
13	Serial Number	4	(HEX)	
14	Tail Character	1	\$	\$

- ✧ **<Mode>**: A numeral to indicate the working mode of light sensor alarm.
  - 0: Disable light sensor alarm.
  - 1: Enable light sensor alarm: The device will send the **+RESP:GTLSA** message when the detected light intensity is higher than **<Sensitivity Threshold>**.
  - 2: Enable light sensor alarm: The device will send the **+RESP:GTLSA** message when the light intensity detected is lower than **<Sensitivity Threshold>**.
- ✧ **<Sensitivity Threshold>**: The level of sensitivity to detect light intensity. The smaller the parameter is, the more sensitive the detection will be.
- ✧ **<Duration>**: If **<Mode>** is not 0 and the light intensity maintains a period of time specified by **<Duration>**, the light sensor alarm event will be triggered.
- ✧ **<Send interval>**: The send interval for the light sensor alarm report when the device enters into light sensor alarm status. 0 means "The light sensor alarm will only be reported once."
- ✧ **<End Report>**: The device reports the **+RESP:GTLSA** message when it exits the light sensor alarm status. 1 means "Enable this parameter", and 0 means "Disable this parameter".
- ✧ **<Report mode>**: A numeral to configure how to report **+RESP:GTLSA** when light sensor status changes.
  - 1: Report the last fixed position.
  - 2: Report the current position.
  - 3: Report the last fixed position immediately, and then turn on GPS to get the current position and report position information again.
- ✧ **<Enable Continuous Mode>**: If it is enabled and the detected light intensity is higher than **<Sensitivity Threshold>**, the device enters continuous mode, otherwise enters power saving mode.

The acknowledgment message of the **AT+GTLTA** command:

➤ **+ACK:GTLTA,**

Example: <b>+ACK:GTLTA,DE0114,135790246811220,,0010,20090214093254,11F0\$</b>			
Parameter	Length	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9', 'a' – 'z', 'A' – 'Z','-', '_'	
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.3.4. Light Tamper Alarm

The **AT+GTLTA** command is used to configure the light tamper alarm function.

➤ **AT+GTLTA=**

Example: <b>AT+GTLTA=gI500m,0,,3,0,0,2,,,,,FFFF\$</b>				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 – 20	'0' – '9', 'a' – 'z', 'A' – 'Z'	<b>gI500m</b>
2	Mode	1	0 1	0
3	Reserved	0		
4	Duration	<= 2	3 – 30	3
5	Send Interval	<= 3	0 10 – 300 (sec)	0
6	End Report	1	0 1	0
7	Report Mode	1	1 – 3	2
8	Reserved	0		
9	Reserved	0		
10	Reserved	0		
11	Reserved	0		
12	Reserved	0		
13	Serial Number	4	(HEX)	
14	Tail Character	1	\$	\$

✧ **<Mode>**: A numeral to indicate the working mode of light sensor tamper alarm

- 0: Disable light tamper alarm.
- 1: Enable light tamper alarm. The device will send the **+RESP:GTLTA** message when

light sensor tamper detected.

- ✧ **<Duration>**: If **<Mode>** is not 0 and the light intensity maintains a period of time specified by **<Duration>**, the light sensor alarm event will be triggered.
- ✧ **<Send interval>**: The send interval for the light sensor alarm report when the device enters into light sensor alarm status. 0 means "The light sensor alarm will only be reported once."
- ✧ **<End Report>**: The device reports the **+RESP:GTLTA** message when it exits the light sensor alarm status. 1 means "Enable this parameter", and 0 means "Disable this parameter".
- ✧ **<Report mode>**: A numeral to configure how to report **+RESP:GTLTA** when light sensor status changes.
  - 1: Report the last fixed position.
  - 2: Report the current position.
  - 3: Report the last fixed position immediately, and then turn on GPS to get the current position and report position information again.

The acknowledgment message of the **AT+GTLTA** command:

➤ **+ACK:GTLTA,**

Example: <b>+ACK:GTLTA,DE0114,135790246811220,,0010,20090214093254,11F0\$</b>			
Parameter	Length	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' - '9', 'a' - 'z', 'A' - 'Z', '-', '_',	
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.4. Bluetooth Setting

#### 3.2.4.1. Bluetooth Setting

The command **AT+GTBTS** is used to enable Bluetooth or not.

➤ **AT+GTBTS=**

Example: <b>AT+GTBTS=gl500m,0,,,,,,,,,,,,,FFFF\$</b>				
SN	Parameter	Length(byte)	Range/Format	Default
1	Password	4 - 20	'0' - '9' 'a' - 'z' 'A' - 'Z'	gl500m
2	Mode	1	0 1 2	0



3	Reserved	0		
4	Reserved	0		
5	Reserved	0		
6	Reserved	0		
7	Reserved	0		
8	Reserved	0		
9	Reserved	0		
10	Reserved	0		
11	Reserved	0		
12	Reserved	0		
13	Reserved	0		
14	Reserved	0		
15	Reserved	0		
16	Reserved	0		
17	Reserved	0		
18	Reserved	0		
19	Reserved	0		
	Serial Number	4	0000 – FFFF	
	Tail Character	1	\$	\$

✧ <Mode>: The working mode of the Bluetooth.

- 0: Disable the Bluetooth.
- 1: Enable the Bluetooth after power on.

### 3.2.4.2. Bluetooth Accessory Setting

The command **AT+GTBAS** is used to scan or connect the device with Bluetooth accessories which contain some effective data such as temperature/humidity. The parameter <Mode> in the command **AT+GTBTS** must be 1 to use the function.

➤ **AT+GTBAS=**

Example:				
AT+GTBAS=gl500m,0,2,0,,B84BA4C0B801,001E,30,2400,,0,0,10,2,300,,0,0,0,0,,,FFFF\$				
SN	Parameter	Length(byte)	Range/Format	Default
1	Password	4 – 20	'0' – '9' 'a' – 'z' 'A' – 'Z'	gl500m
2	Index	1	0 – 9	0

Threshold	< 4	0 – 5555mV	2400
	0		
Optional)	0		
Optional)	0		
Optional)	0		
Optional)	0		
Optional)	0		
	<=4	0-FFFF	
	0		
	0		
	0		
	0		
	0		
	0		
er	4	0000 – FFFF	
	1	\$	\$

- 0: No Bluetooth accessory.
- 1: Reserved.
- 2: Beacon temperature sensor. Five reserved parameters are used as follows:

Mode	1	0-3	0
------	---	-----	---

Low Temperature	<=3	-40 – 80℃	0
High Temperature	<=3	-40 – 80℃	10
Validity	<=2	1 – 10sec	2
Send Interval	2-5	30 - 43200	300

The device will report **+RESP:GTBAA** message to the backend server when the temperature outside or inside the range is detected.

- ✧ **<Mode>**: The working mode of the temperature alarm.
  - 0: Disable temperature alarm.
  - 1: Report temperature alarm if the current temperature is within the temperature range defined by **<Low Temperature>** and **<High Temperature>**.
  - 2: Report temperature alarm if the current temperature is outside the temperature range defined by **<Low Temperature>** and **<High Temperature>**.
  - 3: Report temperature alarm only once if the current temperature enters/exits the temperature range defined by **<Low Temperature>** and **<High Temperature>**. In this mode, **<Send Interval>** will be ignored.
- ✧ **<Low Temperature>**: Specify the lower limit temperature. When the temperature of the sensor is below this value, the device will report message **+RESP:GTBAA** to back server.
- ✧ **<High Temperature>**: Specify the upper limit temperature. When the temperature of the sensor is above this value, the device will report message **+RESP:GTBAA** to back server.
- ✧ **<Validity>**: If the sensor detects the environment temperature meets the alarm condition, it will continuously check the temperature based on the timer set by **<Read Interval>**. If the temperature keeps meeting the alarm condition for **<Validity>**, the temperature alarm will be triggered.
- ✧ **<Send Interval>**: The interval between two messages.
  - 3: Reserved
  - 4: Reserved
  - 5: Reserved
  - 6: Beacon Temperature/humidity Sensor. Five reserved parameters are used as follows:

Temp Mode   Hum Mode	3	0-3 & 0-3	0 0
Low Temperature   Humidity	<=7	-40 – 80℃   0 - 100	0 20
High Temperature   Humidity	<=7	-40 - 80℃   0 - 100	10 80
Validity	<=2	1 – 10sec	2
Send Interval	2-5	30 - 43200	300

The device will report **+RESP:GTBAA** message to the backend server when the temperature/humidity outside or inside the range is detected.

- ✧ **<Temp Mode | Hum Mode>**: “Temp Mode” indicates the working mode of temperature alarm, and “Hum Mode” indicates the working mode of humidity

alarm. The two modes are separated by '|'.

- 0: Disable alarm.
- 1: Report alarm if the current temperature/humidity is within the range defined by <Low Temperature | Humidity> and <High Temperature | Humidity>.
- 2: Report alarm if the current temperature/humidity is outside the temperature range defined by <Low Temperature | Humidity> and <High Temperature | Humidity>.
- 3: Report alarm only once if the current temperature/humidity enters/exits the range defined by <Low Temperature | Humidity> and <High Temperature | Humidity>. In this mode, <Send Interval> will be ignored.
- ✧ <Low Temperature | Humidity>: Specify the lower limit temperature/humidity. When the temperature/humidity of the sensor is below this value, the device will report message **+RESP:GTBAA** to back server.
- ✧ <High Temperature | Humidity>: Specify the upper limit temperature/humidity. When the temperature/humidity of the sensor is above this value, the device will report message **+RESP:GTBAA** to back server.
- ✧ <Validity>: If the sensor detects the environment temperature/humidity meets the alarm condition, it will continuously check the temperature/humidity based on the timer set by <Read Interval>. If the temperature/humidity keeps meeting the alarm condition for <Validity>, the temperature/humidity alarm will be triggered.
- ✧ <Send Interval>: The interval between two messages.
- ✧ <Accessory Model>: The model of the Bluetooth accessory defined in <Accessory Type>. The following is supported now:
  - The model for <Accessory Type> 2 (Beacon Temperature Sensor):  
0: WTS300.
  - The model for <Accessory Type> 6 (Beacon Temperature/humidity Sensor):  
0: WTH300.
- ✧ <Accessory Name>: The name of the Bluetooth accessory.
- ✧ <Accessory MAC>: The MAC address of the Bluetooth accessory.
- ✧ <Append Mask>: Bitwise mask to configure the composition of Bluetooth accessory info. If the device obtains the data from Bluetooth accessories and the Bit 8 for the Bluetooth accessory data of <ERI Mask> in **AT+GTFRI** is set to 1, the device will report **+RESP:GTERI** including the data obtained from Bluetooth accessories instead of **+RESP:GTFRI**. In **+RESP:GTBAA** message, the Bluetooth accessories data will be included according to the mask set by this field.
  - Bit 0: Bluetooth accessory name.
  - Bit 1: Bluetooth accessory MAC.
  - Bit 2: Bluetooth accessory connection status. 1 means the beacon is connected and 0 means the beacon not connected.
  - Bit 3: Bluetooth accessory battery voltage.
  - Bit 4: Bluetooth accessory temperature.
  - Bit 5: Bluetooth accessory humidity.

- ✧ **<Read Interval>**: The interval for reading data from the Bluetooth accessory.
- ✧ **<Low Voltage Threshold>**: Specify the lower limit voltage. When the voltage of Bluetooth accessory is below this value, the device will report message **+RESP:GTBAA** to backend server. 0 means disable low voltage detection.

### 3.2.5. Other Settings

#### 3.2.5.1. Real Time Operation

The **AT+GTRTO** command is used to retrieve information from the terminal or control the terminal to execute certain actions.

##### ➤ **AT+GTRTO=**

**Example:**

**AT+GTRTO=g!500m,2,BSI,,,,,FFFF\$**

SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 – 20	'0' – '9', 'a' – 'z', 'A' – 'Z'	g!500m
2	Sub Command	<=2	1 ~ 8/B/D/E/F	
3	AT Command   Configuration Mask   ATI Mask	3 16 8	"SRI" 0000000000000000 0-FFFFFFFFFFFFFFFF 00 000000 – FFFFFFFF	
4	Reserved	0		
5	Reserved	0		
6	Reserved	0		
7	Reserved	0		
8	Serial Number	4	(HEX)	
9	Tail Character	1	\$	\$

- ✧ **<Sub Command>**: A numeral to indicate the sub command to be executed.
  - 1: **(RTL)**: Request the device to report its current position.
  - 2: **(READ)**: Get the current configuration of the terminal via message **+RESP: GTALM** or **+RESP: GTALS** or **+RESP: GTALC** or **+RESP:GTALL**.
  - 3: **(REBOOT)**: Reboot the device remotely.
  - 4: **(RESET)**: Reset all parameters to factory defaults except the parameters of **AT+GTBSI**, **AT+GTSRI**, **AT+GTPIN**.
  - 5: **(PWROFF)**: Power off the device remotely.
  - 6: **(CID)**: Request the device to report the ICCID of the installed SIM card.
  - 7: **(CSQ)**: Request the device to report the current network signal level.
  - 8: **(VER)**: Request the device to report version information including the device type, the firmware version, and the hardware version.
- B: **(TMZ)**: Get the time zone settings via report **+RESP:GTTMZ**.
- C: **(GIR)**: Get cell information via message **+RESP:GTGSM**.
- D: **(AIF)**: Get APN, ICCID, base station ID, RSSI, Cell ID, and IP via **+RESP:GTAIF**.
- E: **(GSV)**: Request the device to report the GPS fix level. The corresponding information will be reported via the message **+RESP:GTGSV**.

F: **(INF)**: Request the device information report. The corresponding information will be reported via the message **+RESP:GTINF**.

11-13: Reserved

14: **(DELBUF)**: Delete all the buffered reports.

1C: **(ATI)**: Get device basic information via the message **+RESP:GTATI**.

✧ **<AT Command/Configuration Mask/ATI Mask>**:

- **<AT Command>**: To get a single AT command's configuration when **<Sub Command>** is set to 2, follow the format in the following example. For example, to get the configuration of AT+GTCFG, please set AT+GTRTO=gl500m,2,CFG,,,,,0015\$, and get it via **+RESP:GTALS**.
- **<Configuration Mask>**: If **<Sub Command>** is set to 2, the configuration information of the specified **<Configuration Mask>** can be obtained via the message **+RESP:GTALC**. The Configuration Mask must be 16 bytes. If it's less than 16 bytes, '0' will be added in the high bytes of the Configuration Mask.

**Configuration Mask Table:**

Bit	Item to Mask
Bit21 ~ Bit 63	Reserved
Bit20	BTS
Bit19	BAS
Bit18	HRM
Bit17	UPC
Bit16	GLM
Bit15	WLT
Bit14	Reserved
Bit 13	Reserved
Bit12	LTA
Bit11	LSA
Bit10	TEM
Bit9	GEO
Bit8	PDS
Bit7	NMD
Bit6	TMA
Bit5	DOG
Bit4	PIN
Bit 3	CFG
Bit 2	Reserved
Bit 1	SRI
Bit 0	BSI

- **ATI Mask**: If **<Sub Command>** is set to 0x1C, the basic information will be reported via the message **+RESP:GTATI** according to the chosen items in **<ATI Mask>**.

**ATI Mask Table:**

Mask Bit	Item
Bit 0	Firmware Version

Bit 1	Hardware Version
Bit 2	Bootloader Version
Bit 3	Modem Hardware Version
Bit 4	Modem Software Version
Bit 5 ~ Bit 31	Reserved

If <Sub Command> is set to 2, and this parameter field is left empty, the device will report all the configurations via **+RESP:GTALL**.

The acknowledgement message of the **AT+GTRTO** command:

➤ **+ACK:GTRTO,**

Example: <b>+ACK:GTRTO,DE0114,352948070074301,,GPS,000B,20161005172830,11F0\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
Sub Command	<=6	Sub command string	
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.5.2. White Number List Configuration

The **AT+GTWLT** command is used to set up the white number list.

➤ **AT+GTWLT=**

Example: <b>AT+GTWLT=gl500m,1,1,2,13813888888,13913999999,,,,,000C\$</b>				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 – 20	'0' – '9', 'a' – 'z', 'A' – 'Z'	gl500m
2	Number Filter	1	0 1	0
3	Phone Number Start	<=2	1 - 10	
4	Phone Number End	<=2	1 - 10	
5	White Number List	<=20*10		
6	Reserved	0		
7	Reserved	0		
8	Reserved	0		
9	Reserved	0		
10	Serial Number	4	(HEX)	
11	Tail Character	1	\$	\$

- ✧ **<Number Filter>**: A numeral to indicate whether to filter the original number according to **<White Number List>** before implementation of SMS commands.
  - 0: SMS commands will be implemented no matter whether the original number is in the **<White Number List>**.
  - 1: SMS commands will be implemented only when the original number is in the **<White Number List>**.
- ✧ **<Phone Number Start>**: A numeral to indicate the first index of the White Number List numbers to be input. For example, if it is **1**, the device will update the White Number List from the **1st** number. If it is empty, there should be no **<White Number List>**.
- ✧ **<Phone Number End>**: A numeral to indicate the last index of the White Number List numbers to be input. For example, if it is **2**, the device will update the whitelist numbers until the **2nd** one. If it is empty, there should be no **<White Number List>**.
- ✧ **<White Number List>**: A White Number List of phone numbers. Two adjacent phone numbers are separated with ",". The number of the phone numbers in the list is determined by the parameters **<Phone Number Start>** and **<Phone Number End>**. For example, if **<Phone Number Start>** is **1** and **<Phone Number End>** is **2**, the **<White Number List>** should include **2** phone numbers and the two numbers are separated by ",".

The acknowledgment message of the **AT+GTWLT** command:

➤ **+ACK:GTWLT**

Example:			
<b>+ACK:GTWLT,DE0114,352948070074301,,000C,20161005085505,0025\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' - '9' 'a' - 'z' 'A' - 'Z' '-' '_'	
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

**Note:** Make sure the size of the command is not greater than 160 bytes if it is sent via SMS.

### 3.2.5.3. Settings for SMS with Google Maps Link

The **AT+GTGLM** command is used to configure whether to send an SMS with a Google Maps link for SOS and GEO events.

➤ **AT+GTGLM=**

Example:				
<b>AT+GTGLM=gl500m,1,1,1,,,,,FFFF\$</b>				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z', '-', '_'	gl500m
2	Google Mode	1	0 1 2	0
3	Phone Number Start	1	1 - 3	



4	Phone Number End	1	1 - 3	
5	Direct Number List	<=20*3		
6	Reserved	0		
7	Reserved	0		
8	Reserved	0		
9	Reserved	0		
10	Serial Number	4	(HEX)	
11	Tail Character	1	\$	\$

- ✧ **<Google Mode>**: A numeral to indicate whether to send an SMS with a Google Maps link to the number in **<Direct Number List>** for SOS event.
  - 0: Do not send an SMS with a Google Maps link to the number in the **<Direct Number List>** for SOS event.
  - 1: Send an SMS with a Google Maps link including the terminal name to the number in the **<Direct Number List>** for SOS event.
  - 2: Send an SMS with a Google Maps link not including the terminal name to the number in the **<Direct Number List>** for SOS event.
- ✧ **<Phone Number Start>**: A numeral to indicate the first index of the direct numbers to be input. For example, if it is **1**, the device will update the direct number list from the **1st** number. If it is empty, there should be no **<Direct Number List>**.
- ✧ **<Phone Number End>**: A numeral to indicate the last index of the direct numbers to be input. For example, if it is **2**, the device will update the direct number list until the **2nd** one. If it is empty, there should be no **<Direct Number List>**.
- ✧ **<Direct Number List>**: A list of phone numbers. Two adjacent phone numbers are separated by ",". The number of the phone numbers in the list is determined by the parameters **<Phone Number Start>** and **<Phone Number End>**. For example, if **<Phone Number Start>** is **1** and **<Phone Number End>** is **2**, the **<Direct Number List>** should include **2** phone numbers and the two numbers are separated by ",".

The acknowledgment message of the **AT+GTGLM** command:

➤ **+ACK:GTGLM,**

Example:			
<b>+ACK:GTGLM,F50601,015181001707687,,0073,20190906073241,00AB\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' - '9', 'a' - 'z', 'A' - 'Z', '-', '_'	
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.5.4. Over-the-Air Configuration Update

The **AT+GTUPC** command is used to download configuration file over the air for the update of the local configuration.

#### ➤ AT+GTUPC=

Example:				
AT+GTUPC=gl500m,0,10,0,0,0,http://www.queclink.com/configure.ini,0,,,,FFFF\$				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 – 20	'0' - '9', 'a' - 'z', 'A' - 'Z'	gl500m
2	Max Download Retries	1	0 – 3	0
3	Download Timeout	<=2	5 – 30(min)	10
4	Download Protocol	1	0	0
5	Enable Report	1	0 1	0
6	Update Interval	<=4	0 – 8760	0
7	Download URL	<=100	URL	
8	Mode	1	0 1	0
9	Reserved	0		
10	Reserved	0		
11	Reserved	0		
12	Serial Number	4	(HEX)	
13	Tail Character	1	\$	\$

- ✧ <Password>: The valid characters for the password include '0'–'9', 'a'–'z', and 'A'–'Z'. The default value is "gl500m".
- ✧ <Max Download Retries>: It specifies the maximum number of retries to download the configuration file upon downloading failure.
- ✧ <Download Timeout>: If downloading is not finished within this time, it will be regarded that the downloading failed.
- ✧ <Download Protocol>: The protocol used to download the file. Only HTTP is supported now. It is set to 0.
- ✧ <Enable Report>: A numeral to indicate whether to send the message **+RESP:GTUPC** to indicate the configuration is updated over the air.
  - 0: Do not report the message **+RESP:GTUPC**.
  - 1: Report the message **+RESP:GTUPC**.
- ✧ <Update Interval>: The time interval in hours for updating the configuration over the air.
- ✧ <Download URL>: It specifies the URL to download the configuration file. If the URL ends with "/", it means it is a path without any file name. <imei>.ini will be added as the file name at the end of URL.
- ✧ <Mode>: A numeral to indicate the working mode of downloading configuration over the air.
  - 0: Disable this function.
  - 1: Enable this function.

The acknowledgement message of the **AT+GTUPC** command:

➤ **+ACK:GTUPC**

Example:			
<b>+ACK:GTUPC,DE0114,352948070074301,,0005,20161005172830,11F0\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

**Note:**

- (1) If the <Download URL> ends with "/", it means it is a path without any file name. <imei>.ini will be added as the file name at the end of URL. If it is larger than 100, an error will be reported.
- (2) The maximum size of configuration file is 32\*200 bytes. If the size of configuration file is larger than 32\*200 bytes, configuration file cannot be downloaded.
- (3) The length of a command should not exceed 200 bytes in the configuration file.
- (4) Make sure there's only one command per line in the configuration file and there should be a "\r\n" between each command.

### 3.2.5.5. SMS Position Request

This command can only be sent via SMS, and will enable the device to send SMS message with a Google Maps hyperlink of the current position immediately.

Command Format	<b>get position</b>
Example	get position

**get position:** It's a command string to request the current position.

## 3.3. Report

### 3.3.1. Position Related Report

#### 3.3.1.1. General Position Report

- **+RESP:GTGEO:** The message for **AT+GTGEO**
- **+RESP:GTRTL:** The message for **AT+GTRTO-RTL**
- **+RESP:GTPNL:** The first location message after the device powers on
- **+RESP:GTNMR:** Non-movement is detected by motion sensor according to the setting of **AT+GTNMD**
- **+RESP:GTDG:** The watchdog rebooting message
- **+RESP:GTFRI/+RESP:GTERI:** The timed message

**Example:**

+RESP:GTGEO,DE0114,015425000020117,gl500m,2,0,1,4,0,0,0,419.4,114.015800,22.538521,20191011065126,0460,0001,253D,AEC3,19,0,,92,0,0,27.6,20191011145127,0044\$

+RESP:GTRTL,DE0114,015425000020117,gl500m,0,0,1,3,0,0,0,116.8,114.015631,22.537277,20191011081006,0460,0001,253D,AEC3,10,0,,92,1,1,28.3,20191011161007,0089\$

+RESP:GTNMR,DE0114,015425000020117,gl500m,0,1,1,0,0,0,0,326.5,114.019362,22.537809,20191011075205,0460,0001,253D,AEC3,21,0,,92,1,1,27.6,20191011160517,0083\$

+RESP:GTDOG,DE0114,015425000020117,gl500m,0,1,1,0,0,0,0,326.5,114.019362,22.537809,20191011075305,0460,0001,253D,AEC3,21,0,,92,1,1,27.6,20191011160617,0082\$

+RESP:GTFRI,DE0114,015425000020117,gl500m,0,0,1,2,0,0,0,326.5,114.019362,22.537809,20191011075126,0460,0001,253D,AEC3,21,0,,92,0,0,28.8,20191011155127,0079\$

Parameter	Length	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
Report ID	1	0 – 4	
Report Type	1	0 – 1	
Number	<=1	1	
GPS Accuracy	<=2	0 – 6	
Speed	<=5	0.0 – 999.9(km/h)	
Azimuth	<=3	0 – 359	
Altitude	<=8	(-)XXXXX.X (m)	
Longitude	<=11	(-)XXX.XXXXXX	
Latitude	<=10	(-)XX.XXXXXX	
GPS UTC Time	14	YYYYMMDDHHMMSS	
MCC	0 4	0XXX	
MNC	0 4	0XXX	
LAC	0 4	XXXX	
Cell ID	<=8	XXXX	
CSQ RSSI	<=2	0 - 31 99	
CSQ BER	<=2	0 - 7 99	
Reserved	0		
Battery Percentage	<=3	0 - 100	
Mode Selection	1	0 1	
Movement Status	1	0 1	
Temperature	<=5	(-)XX.X	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	

Tail Character	1	\$	\$
----------------	---	----	----

- ✧ **<Report ID>**: The ID of Geo-fence in **+RESP:GTGEO**. For the ID of other reports, it is 0.
- ✧ **<Report Type>**: The type of the messages **+RESP:GTGEO**, **+RESP:GTDOG** and **+RESP:GTNMR**. For other reports, it is 0.
  - For **+RESP:GTGEO**
    - 0: Exit the corresponding Geo-fence
    - 1: Enter the corresponding Geo-fence
  - For **+RESP:GTNMR**
    - 0: The state of the device changed from motion to rest
    - 1: The state of the device changed from rest to motion
  - For **+RESP:GTDOG**
    - 0: Reboot periodically according to the **<Interval>** and **<Time>** settings
- ✧ **<Number>**: The number of points in one message. This parameter value is always 1.
- ✧ **<GPS Accuracy>**: A numeral to indicate the GPS fix status and HDOP of the GPS position. 0 indicates the current GPS fix fails and the last known GPS position is used. A non-zero value (1 - 50) indicates the current GPS fix is successful and represents the HDOP of the current GPS position.
- ✧ **<Speed>**: The speed read from GPS.
- ✧ **<Azimuth>**: The azimuth from GPS.
- ✧ **<Altitude>**: The height above sea level from GPS.
- ✧ **<Longitude>**: The longitude of the current position. The format is "**(-)xxx.xxxxxx**" and the value range is from "**-180.000000**" to "**180.000000**". The unit is degree. West longitude is represented as a negative value starting with the minus sign "**-**" and east longitude is represented as a positive value without "**+**".
- ✧ **<Latitude>**: The latitude of the current position. The format is "**(-)xx.xxxxxx**" and the value range is from "**-90.000000**" to "**90.000000**". The unit is degree. South latitude is represented as a negative value starting with the minus sign "**-**" and north latitude is represented as a positive value without "**+**".
- ✧ **<GPS UTC Time>**: UTC time from GPS.
- ✧ **<MCC>**: Mobile country code. It is 3-digit in length and ranges from 000–999. If Bit 3 of the field **<Report Composition Mask>** in **AT+GTCFG** is not set to 1, the length of this field is 0 in ASCII format message.
- ✧ **<MNC>**: Mobile network code. It is 3-digit in length and ranges from 000–999. If Bit 3 of the field **<Report Composition Mask>** in **AT+GTCFG** is not set to 1, the length of this field is 0 in ASCII format message.
- ✧ **<Cell ID>**: Cell ID in hex format.
- ✧ **<CSQ RSSI>**: The signal strength level.
- ✧ **<CSQ BER>**: The quality of the signal. The range is 0-7, and 99 is for unknown signal strength.
- ✧ **<Battery Percentage>**: Current volume of the battery in percentage.
- ✧ **<Mode Selection>**: Current mode of the device.
  - 0: Power saving mode (PSM)
  - 1: Continuous mode
- ✧ **<Movement Status>**: The movement status of the device. It must be noted that the sensor

function must be enabled in the **AT+GTNMD** command, otherwise this field is empty.

- 0: Stillness
- 1: Motion

✧ *<Temperature>*: The real time temperature value of the terminal. It must be noted that the temperature function must be enabled in the in the **AT+GTTEM** command, otherwise this field is empty.

➤ **+RESP:GTERI,**

If the **+RESP:GTERI** is enabled, the device will send the message **+RESP:GTERI** to the backend server instead of **+RESP:GTFRI**.

+RESP:GTERI,DE0114,862061048052830,,00000008,0,0,1,0,0,0,0,137.1,114.013186,22.536606 ,20191206020459,0000,0000,0000,0000,0,0,,81,1,,10,0,6,0,33,WTH300 00 AC233FA248C0 0E10 1B00 1901,003f,,AC233FA248C0,1,3600,27.0,25,20191206023822,00AA\$			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
ERI Mask	8	00000000 – FFFFFFFF	
Report ID	1	0 – 4	
Report Type	1	0 – 1	
Number	<=1	1	
GPS Accuracy	<=2	0 – 6	
Speed	<=5	0.0 – 999.9(km/h)	
Azimuth	<=3	0 – 359	
Altitude	<=8	(-)XXXXX.X (m)	
Longitude	<=11	(-)XXX.XXXXXX	
Latitude	<=10	(-)XX.XXXXXX	
GPS UTC Time	14	YYYYMMDDHHMMSS	
MCC	0 4	0XXX	
MNC	0 4	0XXX	
LAC	0 4	XXXX	
Cell ID	<=8	XXXX	
CSQ RSSI	<=2	0 - 31 99	
CSQ BER	<=2	0 - 7 99	

Reserved	0		
Battery Percentage	<=3	0 - 100	
Mode Selection	1	0 1	
Movement Status	1	0 1	
Bluetooth Accessory Number	<=2	0-10	
Index	1	0 – 9	
Accessory Type	1	0 - 6	
Accessory Model	1	0	
Raw Data Length	2	0 - FF	
Raw Data			
Accessory Append Mask	4	0 - FFFF	
Accessory Name	<=21		
Accessory MAC	12	000000000000 FFFFFFFFFFFF	-
Accessory Connection Status	1	0 - 1	
Accessory Voltage	<=4	0 – 5000mV	
Accessory Temperature	<=3	-40 – 80 °C	
Accessory Humidity	<=3	0-100	
Send Time	0 14	YYYYMMDDHHMMSS	
Count Number	4	0000 – FFFF	
Tail Character	1	\$	\$

- ✧ <ERI Mask>: The mask which is defined in **AT+GTCFG**. This mask is used to configure whether to report the data from peripherals by **+RESP:GTERI**.
- ✧ <Bluetooth Accessory Number>: The number of Bluetooth accessory. If it is 0, the accessory details fields from <Index> to <Accessory Humidity> will not display. If there are more than one Bluetooth accessory, the **+GTERI** report will repeat to show the information of all devices, with one **+GTERI** message contain one Bluetooth accessory.
- ✧ <Index>: The index of Bluetooth accessory defined in **AT+GTBAS** which triggers the **+RESP:GTBAA** message.
- ✧ <Accessory Type>: The type of the Bluetooth accessory which is defined in **AT+GTBAS**.
- ✧ <Accessory Model>: The model of the Bluetooth accessory which is defined in **AT+GTBAS**.
- ✧ <Raw Data Length>: It indicates the length of <Raw Data>.
- ✧ <Raw Data>: The data is read from Bluetooth accessory. It varies depending on <Accessory Type> and <Accessory Model>.

- ✧ <Append Mask>: Bitwise mask defined in **AT+GTBAS** to configure which data item is reported.
- ✧ <Accessory Name>: The name of the Bluetooth accessory. It ends with 0x00.
- ✧ <Accessory MAC>: The MAC address of the Bluetooth accessory.
- ✧ <Accessory Connection Status>: It indicates the connection status of Bluetooth accessory.
  - 0: Disconnected.
  - 1: Connected.
- ✧ <Accessory Voltage>: The voltage of Bluetooth accessory.
- ✧ <Accessory Temperature>: Temperature data of Bluetooth accessory.
- ✧ <Accessory Humidity>: Humidity data of Bluetooth accessory.

**Note:** the key word (optional) means the item is controlled by the parameter <ERI Mask>.

### 3.3.2. Device Information Report

#### ➤ +RESP:GTINF:

<b>Example:</b> <b>+RESP:GTINF,DE0114,015425000020117,g 500m,89860117851023145136,21,0,,0,,92,29.1,20191011075205,0,,,,,,20191011155208,0081\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
ICCID	20		
CSQ RSSI	<=2	0 – 31 99	
CSQ BER	<=2	0 – 7 99	
Reserved	0		
Mode Selection	1	0 1	
Reserved	0		
Battery Percentage	3	0 - 100	
Temperature	<=5	(-)XX.X	
Last GPS Fix UTC Time	14	YYYYMMDDHHMMSS	
<i>Movement Status</i>	1	0 1	
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

- ✧ <ICCID>: The ICCID of the installed SIM card.



- ✧ <CSQ RSSI>: The network signal strength level.
- ✧ <CSQ BER>: The quality of the network signal.
- ✧ <Last GPS Fix UTC Time>: The UTC time of the latest successful GPS fix.
- ✧ <Temperature>: The real time temperature value of the terminal. It must be noted that the temperature function must be enabled in the in the **AT+GTTEM** command, otherwise this field is empty.

### 3.3.3. Report for Querying

The reports for real time querying via the command **AT+GTRTO** are as follows.

#### 3.3.3.1. +RESP:GTALM

After the device receives the command **AT+GTRTO** to read all the configurations, it will send all configurations to the backend server by the message **+RESP:GTALL**. This message is only sent via GPRS/LTE even if the report mode is Force on SMS. If the message's length is too long, then it will be sub-packaged into several **+RESP:GTALM** messages. The **+RESP:GTALM** does not support HEX report.

➤ **+RESP:GTALM,**

**Example:**

```
+RESP:GTALM,DE0114,015425000021222,GL500M,2,1,BSI,2gnet,,,iot.aer.net,,,1,2,SRI,3,,0,218.
17.46.11,65535,218.17.46.11,65534,15889570956,0,0,0,10,0,,CFG,gl500m,GL500M,,0823,003F,
1,5,111111111111111,1,1200,0,24,24,1,1,5,0,0000,1,1,10,2,,1,2,PIN,0,,,,,DOG,0,,7,0200,,1,0,,,
TMA,+,08,00,0,,,,,NMD,0,0,3,3,2,1440,2,,,,,PDS,0,00000019,,,,,GEO,0,0,114.016144,22.537
659,50,,,,,1,0,114.016144,22.537659,50,,,,,2,0,114.016144,22.537659,50,,,,,3,0,114.0
16144,22.537659,50,,,,,4,0,-180.000000,22.537659,50,,,,,5,0,22.537659,22.537659,50,,,,
,,,,6,0,22.537659,22.537659,50,,,,,7,0,22.537659,22.537659,50,,,,,8,0,22.537659,22.5376
59,50,,,,,9,0,22.537659,22.537659,50,,,,,10,0,22.537659,22.537659,50,,,,,11,0,22.5376
59,22.537659,50,,,,,12,0,22.537659,22.537659,50,,,,,13,0,22.537659,22.537659,50,,,,,
14,0,22.537659,22.537659,50,,,,,15,0,22.537659,22.537659,50,,,,,16,0,22.537659,22.537
659,50,,,,,17,0,22.537659,22.537659,50,,,,,18,0,22.537659,22.537659,50,,,,,19,0,22.53
7659,22.537659,50,,,,,TEM,1,0,0,0,60,300,0,,,,LSA,0,5,3,0,0,2,0,,,,LTA,0,,3,0,0,2,,,,DMS,0,q
ueclinkDM,1,queclink.3322.org,8020,,,1,779F,,0,,0,100,,WLT,0,1,10,15889570956,15889570956
,15889570956,15889570956,15889570956,15889570956,15889570956,15889570956,15889570
956,15889570956,,,,,20200103150303,018C$
```

Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	XX0000 – XXXFFF, X ∈ {'A' – 'Z', '0' – '9'}	
Unique ID	15	IMEI	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
Total Packets	2	10	
Current Packet	<=2	1 – 10	

Configurations	< 1500		
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	0000 – FFFF	
Tail Character	1	\$	\$

- ✧ <Total Packets>: The total number of **+RESP:GTALM**.
- ✧ <Current Packet>: The sequence number of current packet.
- ✧ <Configurations>: The current configuration of the device.

**Note:** The length of every **+RESP:GTALM** message (including header and tail) should be no more than 1500 characters.

### 3.3.3.2. +RESP:GTALC

After the device receives the command **AT+GTRTO** to read the configurations, it will send corresponding configuration information to the backend server via the message **+RESP:GTALC** according to the configuration mask. The **+RESP:GTALC** does not support the HEX report.

#### ➤ +RESP:GTALC

##### Example:

```
+RESP:GTALC,DE0114,015425000020117,gl500m,BSI,3gnet,,,,,1,0,SRI,3,,1,218.17.46.11,65535,
218.17.46.11,65534,15889570956,0,0,0,0,,CFG,gl500m,gl500m,,0823,003F,0,120,1010101010
1110,1,1200,0,1,24,1,2,5,0,0005,0,0,10,0,,,TMA,+,08,00,0,,,,,GEO,0,0,114.017775,22.538215,5
0,,,,,,1,2,114.017775,22.538215,50,,,,,,2,0,114.019970,22.534216,50,,,,,,3,0,0.000000,0.0
00000,50,,,,,,4,0,0.000000,0.000000,50,,,,,,NMD,1,7,3,3,2,1440,1,,,,,,PIN,1,1234,,,,,DOG,1
,,1,0200,,1,,1,,,WLT,0,1,1,,,,,,TEM,1,3,0,50,60,300,0,,,,UPC,1,10,0,1,0,http://szqueclink.f
3322.net:9129/GL500M/deltabin/test.ini,1,,,,PDS,1,00000019,,,,,LSA,1,5,3,0,1,2,0,,,,LTA,1,,3,
0,1,2,,,,,20191011163130,00BA$
```

Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
Configuration Mask	16	0000000000000000 - FFFFFFFFFFFFFFFF	
BSI	3	BSI	BSI
LTE APN	<=40		
LTE APN User Name	<=30		
LTE APN Password	<=30		
GPRS APN	<=40		
GPRS APN User Name	<=30		
GPRS APN Password	<=30		
Network Mode/APN Authentication Methods	1	00 - 33	0
LTE Mode	1	0 - 3	0

SRI	3	SRI	SRI
Report Mode	1	0 – 5	0
Reserved	0		
Enable Buffer	1	0 - 2	1
Main Server IP/ Domain Name	<=60		
Main Server Port	<=5	0 – 65535	0
Backup Server IP/Domain Name	<=60		
Backup Server Port	<=5	0 – 65535	0
SMS Gateway	<=20		
Heartbeat Interval	<=3	0 10 – 360(min)	0
Enable SACK	1	0-2	0
Enable SMS ACK	1	0 1	0
Network hold time	<=5	0 - 86400(sec)	300
Protocol Format	1	0 1	
Reserved	0		
CFG	3	CFG	CFG
New Password	4 – 20	'0' – '9', 'a' – 'z', 'A' – 'Z'	
Device Name	<=20	'0' – '9', 'a' – 'z', 'A' – 'Z', '-', '_'	gl500m
Reserved	0		
Event Mask	4	0000 – 0FFF	0823
Report Item Mask	<=4	0000 – 003F	001F
Mode Selection	1	0 1	
Continuous Send Interval	<=4	0 1-1440(min)	5
Week Report Selection	14		10101010101010
Start Mode	1	0-2	0
Specified Time of Day	4	HHMM	1200
Adjustment Enable	1	0-1	0
Initial Wakeup Interval	<=2	1 – 4 6 8 12 24	1
Final Wakeup Interval	<=2	1 – 4 6 8 12 24	24
Hold Days	<=2	1 – 99	1
Report Frequency	<=3	1 – 100	1
GPS Fix Delay	2	5 – 60(sec)	5
AGPS Mode	1	0 1	0
GSM Report	4	0000 -FFFF	0
Motor Vibration Time	1	0 - 9 (*100ms)	0
Reserved	0		
Battery Low Percentage	<=2	0 - 30	10
Function Key Mode	1	0-2	0
Reserved	0		

SOS Report Mode	1	0-2	1
Location Request Mask	1	0 2	2
PIN	3	PIN	PIN
Auto Unlock PIN	1	0 1	0
PIN	4-8	'0' - '9'	
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
DOG	3	DOG	DOG
Mode	1	0 - 2	1
Reserved	0		
Interval	<=2	1 - 30(days)	7
Time	4	HHMM	0200
Reserved	0		
Report Before Reboot	1	0 1	1
Reserved	0		
Unit	1	0 1	0
Reserved	0		
Reserved	0		
Reserved	0		
TMA	3	TMA	TMA
Sign	1	+ -	+
Hour Offset	<=2	0 - 12	00
Minute Offset	<=2	0 - 59	00
Daylight Saving	1	0 1	0
UTC Time	14	YYYYMMDDHHMMSS	
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
NMD	3	NMD	NMD
Sensor Enable	1	0-1	0
Mode	1	0-F	0
Non-movement Duration	<=3	1 – 200(*15sec)	3
Movement Duration	<=2	3 – 50(*100ms)	3
Movement Threshold	1	2 – 9	2
Rest Send Interval	<=4	5 - 1440 (min)	
Report Mode	1	1 - 3	2
Reserved	0		
Reserved	0		

Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
PDS	3	PDS	PDS
Mode	1	0 - 2	1
Mask	8	00000000-FFFFFFFF	00000019
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
GEO	3	GEO	GEO
GEO ID0	<=2	1	1
Mode	1	0 - 3	0
Longitude	<=11	(-)XXX.XXXXXX	
Latitude	<=10	(-)XX.XXXXXX	
Radius	<=7	50 - 6000000(min)	50
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
GEO ID1	<=2	1	1
Mode	1	0 - 3	0
Longitude	<=11	(-)XXX.XXXXXX	
Latitude	<=10	(-)XX.XXXXXX	
Radius	<=7	50 - 6000000(min)	50
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		

Reserved	0		
:	:	:	:
GEO ID19	<=2	19	19
Mode	1	0 – 3	0
Longitude	<=11	(-)XXX.XXXXXX	
Latitude	<=10	(-)XX.XXXXXX	
Radius	<=7	50 – 6000000(min)	50
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
TEM	3	TEM	TEM
Temperature Enable	1	0 1	0
Mode	1	0 - 3	0
Min. Temperature	3	-20 – +60	0
Max. Temperature	3	-20 – +60	0
Duration	<=4	10 – 3600(sec)	60
Send Interval	<=4	0 10 – 3600(sec)	300
Enable Continuous Mode	0	0 1	0
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
LSA	3	LSA	LSA
Mode	1	0 - 2	0
Sensitivity Threshold	1	1 - 9	5
Duration	<= 2	3 – 30	3
Send Interval	<= 3	0 10 – 300 (sec)	0
End Report	1	0 1	0
Report Mode	1	1 - 3	2
Enable Continuous Mode	0	0 1	0
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
LTA	3	LTA	LTA

Mode	1	0 1	0
Reserved	0		
Duration	<= 2	3 – 30	3
Send Interval	<= 3	0 10 – 300 (sec)	0
End Report	1	0 1	0
Report Mode	1	1 - 3	2
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
WLT	3	WLT	WLT
Call Filter	1	0 1	0
Phone Number Start	<=2	1 - 10	0
Phone Number End	<=2	1 - 10	
White Number List Number	<=20		
White Number List Number	<=20		
White Number List Number	<=20		
White Number List Number	<=20		
White Number List Number	<=20		
White Number List Number	<=20		
White Number List Number	<=20		
White Number List Number	<=20		
White Number List Number	<=20		
White Number List Number	<=20		
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
GLM	3	GLM	GLM
GLM	3	GLM	0
Google Mode	1	0 1 2	
Direct Number	<=20		

Direct Number	<=20		
Direct Number	<=20		
Reserved	0		
Reserved	0		
Reserved	0		
UPC	3	UPC	UPC
Max. Download Retries	1	0 – 3	0
Download Timeout	<=2	5 – 30(min)	10
Download Protocol	1	0	0
Enable Report	1	0 1	0
Update Interval	1	0 – 8760	0
Download URL	<=100	URL	
Mode	1	0 1	0
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
HRM	3	HRM	HRM
Reserved	0		
Reserved	0		
+ACK Mask	4	(HEX)	7F
+RSP Mask	4	(HEX)	FF7F
+EVT Mask	4	(HEX)	FF7F
+INF Mask	4	(HEX)	F77F
+HBD Mask	4	(HEX)	7F
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

**Note:** Regardless the report mode setting, **+RESP:GTALC** is only reported through TCP/UDP. If current report mode is Force on SMS, **+RESP:GTALC** will still be reported via TCP/UDP.

### 3.3.3.3. +RESP:GTCID

After the device receives the command **AT+GTRTO** to read the ICCID of the SIM card, it will send the ICCID to the server by the report **+RESP:GTCID**.

#### ➤ +RESP:GTCID

**Example:**

**+RESP:GTCID,DE0114,015425000020117,gI500m,89860117851023145136,20191011163149,0  
OBD\$**



Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
ICCID	20		
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.3.3.4. +RESP:GTCSQ

After the device receives the command **AT+GTRTO** to read the GPRS/LTE signal level, it will send the GPRS/LTE signal level to the backend server by the message **+RESP:GTCSQ**.

#### ➤ +RESP:GTCSQ

<b>Example:</b> <b>+RESP:GTCSQ,DE0114,015425000020117,gl500m,18,99,20191011163153,00BF\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
CSQ RSSI	<=2	0 – 31   99	
CSQ BER	<=2	0 – 7   99	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.3.3.5. +RESP:GTVR

After the device receives the command **AT+GTRTO** to get the versions (including firmware version, hardware version and module version), it will send the version information to the backend server by the message **+RESP:GTVR**.

#### ➤ +RESP:GTVR

<b>Example:</b> <b>+RESP:GTVR,DE0114,015425000020117,gl500m,0902,0106,,BG96,BG96MAR02A07M1G,20191011161008,008B\$</b>			
Parameter	Length	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
Firmware Version	4	(HEX)	
Hardware Version	4	(HEX)	
Reserved	4	0000	0000

Modem Hardware Version	<=20		
Modem Software Version	<=50		
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

- ✧ *<Firmware Version>*: The firmware version of the device. The first two characters indicate the major version and the last two characters indicate the minor version. For example, 010A means version 1.10.
- ✧ *<Hardware Version>*: The hardware version of the device. The first two characters indicate the major version and the last two characters indicate the minor version. For example, 010A means version 1.10.
- ✧ *<Modem Hardware Version>*: It gives the modem hardware information of this device.
- ✧ *<Modem Software Version>*: It gives the modem software version information of this device.

### 3.3.3.6. +RESP:GTTMZ

After the device receives the command **AT+GTRTO** to get the time zone settings, it will send the time zone information by the message **+RESP:GTTMZ** to the backend server.

➤ **+RESP:GTTMZ,**

Example: <b>+RESP:GTTMZ,DE0112,015425000020257,,+0000,0,20191226074345,000C\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	XX0000 – XXFFFF, $X \in \{'A' - 'Z', '0' - '9'\}$	
Unique ID	15	IMEI	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
Time Zone Offset	5	±HHMM	
Daylight Saving	1	0 1	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	0000 – FFFF	
Tail Character	1	\$	\$

### 3.3.3.7. +RESP:GTAIF

After the device receives the command **AT+GTRTO** to get the **AIF**, it will send the information by the report **+RESP:GTAIF** to the server. The **+RESP:GTAIF** does not support the HEX report.

➤ **+RESP:GTAIF,****Example:**

**+RESP:GTAIF,DE0114,868446036599153,gl500m,,,,,,,,,89860117851023145722,16,0,AEC3,10.100.13.247,,,,,,,,1,20190823114121,116A\$**

Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	XX0000 – XXFFFF, X ∈ {'A' – 'Z', '0' – '9'}	
Unique ID	15	IMEI	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
LTE APN	<=47		
LTE APN User Name	<=30		
LTE APN Password	<=30		
GPRS APN	<=47		
GPRS APN User Name	<=30		
GPRS APN Password	<=30		
ICCID	20		
CSQ RSSI	<=2	0 – 31	
CSQ BER	<=2	0 – 7/99	
Cell ID	0/4/8	XXXXXXXX	
IP Address	7	0.0.0.0	
Main DNS	7	0.0.0.0	
Backup DNS	7	0.0.0.0	
Reserved			
Reserved			
Reserved			
Network Type	1	0,1,3	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	0000 – FFFF	
Tail Character	1	\$	\$

✧ <CSQ RSSI>: The signal strength level.

CSQ RSSI	Signal Strength (dBm)
0	<-133

1	-111
2 – 30	-109 – -53
31	>-51

- ✧ <CSQ BER>: The strength of the signal. The range is 0-7 and 99 means unknown.
- ✧ <Cell ID>: Cell ID in hex format.
- ✧ <IP Address>: The IP address of the device.
- ✧ <Main DNS>: The main DNS server.
- ✧ <Backup DNS>: The backup DNS server.
- ✧ <Network Type>: Current network type.
  - 0: Unregistered.
  - 1: 2G
  - 3: 4G

### 3.3.3.8. +RESP:GTALS

After the device receives the command **AT+GTRTO** to get sub AT command configuration information, it will send the configuration information to the backend server by the message **+RESP:GTALS**. Different AT Command gets different configuration information. For example, to get BSI configuration: **AT+GTRTO=gl500m,2,BSI,0,,,,,FFFF\$**

#### ➤ +RESP:GTALS

**Example:**

**+RESP:GTALS,DE0114,866425030719696,,BSI,cmnet,,,,,1,2, 20180921161511,005B\$**

Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' - '9' 'a' - 'z' 'A' - 'Z' '-' '_'	
BSI	3	BSI	
APN	<=64	(ASCII)	
APN User Name	<=30	(ASCII)	
APN Password	<=30	(ASCII)	
Backup APN	<=40	(ASCII)	
Backup APN User Name	<=30	(ASCII)	
Backup APN Password	<=30	(ASCII)	
Network Mode	1	0 - 2	
LTE Mode	1	0 - 3	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.3.3.9. +RESP:GTGSV

After the device receives the command to get satellite information, it will send the satellite information via the message **+RESP:GTGSV** to the backend server. The **+RESP:GTGSV** does not

support the HEX report.

➤ **+RESP:GTGSV**

**Example:**

**+RESP:GTGSV,DE0114,015425000020117,gl500m,11,2,42,5,27,6,35,7,0,9,33,12,33,17,32,19,35,25,25,29,46,30,18,20191011110234,0008\$**

Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
SV Count	<=2	0 - 16	
SV ID	<=2	0-50	
SV Power	<=2	0-55	
... ..			
SV ID	<=2	0-50	
SV Power	<=2	0-55	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

- ✧ <SV Count>: The count of satellites the GPS finds.
- ✧ <SV ID>: The satellite ID. In case of no satellite, the field is filled with zero.
- ✧ <SV Power>: Satellite power. In case of no satellite, the field is filled with zero.

### 3.3.3.10. +RESP:GTATI

After the device receives the command **AT+GTRTO** to get the basic device information, it will send the information to the backend server via the message **+RESP:GTATI**.

➤ **+RESP:GTATI**

**Example:**

**+RESP:GTATI,DE0114,015425000021222,GL500M,0,20200109103246,0B1B\$**

Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	XX0000 – XXXFFF, X ∈ {'A' – 'Z','0' – '9'}	
Unique ID	15	IMEI	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	

ATI Mask	<=8	00000000 - 0000001F	
Firmware Version	6	'0' – '9' 'a' – 'z' 'A' – 'Z'	
Hardware Version	4	'0' – '9' 'a' – 'z' 'A' – 'Z'	
Bootloader Version	4	0' – '9' 'a' – 'z' 'A' – 'Z'	
Modem Hardware Version	<=20		
Modem Software Version	<=50		
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	0000 – FFFF	
Tail Character	1	\$	\$

- ✧ <ATI Mask>: This mask is set by **AT+GTRTO** command and used to control parameter fields in the **+RESP:GTATI** message.
- ✧ <Firmware Version>: The firmware version of the device. The first two characters indicate the branch number, the middle two characters indicate the major version and the last two characters indicate the minor version. For example, 010A means version 1.10.
- ✧ <Hardware Version>: The hardware version of the device. The first two characters indicate the major version and the last two characters indicate the minor version. For example, 010A means version 1.10.
- ✧ <Modem Hardware Version>: It gives the modem hardware information of this device.
- ✧ <Modem Software Version>: It gives the modem software version information of this device.

### 3.3.4. Event Report

The following event reports are triggered when certain events occur.

**+RESP:GTPNA**: Power on report

**+RESP:GTPFA**: Power off report

**+RESP:GTBTC**: Battery starts charging report. Only GL501MG supports this report.

**+RESP:GTSTC**: Battery stops charging report. Only GL501MG supports this report.

**+RESP:GTBPL**: Battery low report

**+RESP:GTTEM**: Temperature alarm report

**+RESP:GTUPC**: Configuration updated report

**+RESP:GTGSM**: The report for the information of the serving cell and the neighbor cells, this report does not support the HEX format

**+RESP:GTLSA**: Light sensor alarm report.

**+RESP:GTLTA**: Light sensor tamper alarm report.

**+RESP:GTBAA**: Bluetooth alarm report.

➤ **+RESP:GTPNA**,

**Example:**

**+RESP:GTPNA,DE0114,015425000020117,gl500m,2,20191011160545,0084\$**

Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' ' ' '_'	
Power On Type	<=1	1 - 9	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

✧ <Power On Type>: A numeral to indicate how the terminal is activated.

- 1: Movement detected by the terminal.
- 2: Specified time reached.
- 3: Light sensor alarm event.
- 4: Manual powering on for the first time.
- 5: RTO command or dog reboot.
- 6: Reserved
- 7: RTC error.
- 8: FOTA process.
- 9: Temperature sensor alarm event.

➤ **+RESP:GTPFA**

**Example:**

**+RESP:GTPFA,DE0114,015425000020117,gl500m,20191011161520,0092\$**

Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' ' ' '_'	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

➤ **+RESP:GTBTC,+RESP:GTSTC**

**Example:**

**+RESP:GTBTC,DE0114,352948070074301,100,20191011161253,11F0\$**

Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' ' ' '_'	
Battery Percentage	<=3	0 - 100	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

➤ **+RESP:GTBPL,**

- +RESP:GTTEM,
- +RESP:GTLTA,

Example:			
+RESP:GTBPL,DE0114,015425000020117,g 500m,0,0,1,3,0.0,0,86.5,114.015376,22.537105,20191011081251,0460,0001,253D,AEC3,17,0,,9,0,0,28.8,20191011161253,0090\$			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' - '9' 'a' - 'z' 'A' - 'Z' '-' '_'	
Event State1	<=1	0-4	
Event State2	<=1	0	
Number	<=1	1	
GPS Accuracy	<=2	0 - 6	
Speed	<=5	0.0 - 999.9(km/h)	
Azimuth	<=3	0 - 359	
Altitude	<=8	(-)XXXXX.X (m)	
Longitude	<=11	(-)XXX.XXXXXX	
Latitude	<=10	(-)XX.XXXXXX	
GPS UTC Time	14	YYYYMMDDHHMMSS	
MCC	0 4	0XXX	
MNC	0 4	0XXX	
LAC	0 4	XXXX	
Cell ID	<=8	XXXX	
CSQ RSSI	<=2	0 - 31 99	
CSQ BER	<=2	0 - 7 99	
Reserved	0		
Battery Percentage	<=3	0 - 100	
Mode Selection	1	0 1	
Movement Status	1	0 1	
Temperature	<=5	(-)XX.X	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

For +RESP:GTBPL

- ✧ <Event state1>: 0
- ✧ <Event state2>: 0

For +RESP:GTTEM

- ✧ <Event state1>: The temperature alarm state
  - 1: The current temperature is lower than the low temperature threshold specified by <Min. Temperature>.
  - 2: The current temperature is higher than the high temperature threshold specified by <Max. Temperature>.
  - 3: The current temperature is within the temperature threshold range.



- 4: The current temperature is outside the temperature threshold range.

✧ <Event state2>: 0

For **+RESP:GTLA**

✧ <Event state1>: The light sensor alarm state.

- 0: Normal state
- 1: Above threshold alarm state
- 2: Below threshold alarm state

✧ <Event state2>: 0

For **+RESP:GTLTA**

✧ <Event state1>: The light sensor tamper state.

- 0: Normal state
- 1: Tamper alarm state

✧ <Event state2>: 0

➤ **+RESP:GTLA**

**Example:**  
**+RESP:GTLA,DE0111,866425037440593,gl500m,1,0,1,2,0,0,0,117.3,114.015805,22.537322,20191011042936,0460,0001,253D,AEC3,20,0,5,98,0,0,27.4,20191011122938,06ED\$**

Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' - '9' 'a' - 'z' 'A' - 'Z' '-' '_'	
Event State1	<=1	0-4	
Event State2	<=1	0	
Number	<=1	1	
GPS Accuracy	<=2	0 - 6	
Speed	<=5	0.0 - 999.9(km/h)	
Azimuth	<=3	0 - 359	
Altitude	<=8	(-)XXXXX.X(m)	
Longitude	<=11	(-)XXX.XXXXXX	
Latitude	<=10	(-)XX.XXXXXX	
GPS UTC Time	14	YYMMDDHHMMSS	
MCC	0 4	0XXX	
MNC	0 4	0XXX	
LAC	0 4	XXXX	
Cell ID	<=8	XXXX	
CSQ RSSI	<=2	0 - 31 99	
CSQ BER	<=2	0 - 7 99	
Light Level	1	1 - 9	
Battery Percentage	<=3	0 - 100	
Mode Selection	1	0 1	
Movement Status	1	0 1	

Temperature	<=5	(-)XX.X	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

✧ <Light Level>: The level of light intensity detected by the device.

➤ **+RESP:GTGSM,**

**Example:**

**+RESP:GTGSM,DE0114,015425000020117,gl500m,RTL,0460,0001,253D,AEC3,21,,,,,,,,,,,,,  
,,,,,,0460,0001,253D,AEC3,21,,20191011155127,007C\$**

Parameter	Length	Range/Format	Default
Protocol version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
Fix Type	3	FRI RTL ERI GIR	
MCC1	4	0XXX	
MNC1	4	0XXX	
LAC1	4		
Cell ID1	4		
RX level1	2	0 - 63	
Reserved	0		
MCC2	4	0XXX	
MNC2	4	0XXX	
LAC2	4		
Cell ID2	4		
RX level2	2	0 - 63	
Reserved	0		
MCC3	4	0XXX	
MNC3	4	0XXX	
LAC3	4		
Cell ID3	4		
RX level3	2	0 - 63	
Reserved	0		

MCC4	4	0XXX	
MNC4	4	0XXX	
LAC4	4		
Cell ID4	4		
RX level4	2	0 - 63	
Reserved	0		
MCC5	4	0XXX	
MNC5	4	0XXX	
LAC5	4		
Cell ID5	4		
RX level5	2	0 - 63	
Reserved	0		
MCC6	4	0XXX	
MNC6	4	0XXX	
LAC6	4		
Cell ID6	4		
RX level6	2	0 - 63	
Reserved	0		
MCC	4	0XXX	
MNC	4	0XXX	
LAC	4		
Cell ID	4		
RX Level	2	0 - 63	
Reserved	0		
Send time	14	YYYYMMDDHHMMSS	
Count number	4	(HEX)	
Tail character	1	\$	\$

✧ <Fix Type>: A string which indicates the type of GPS fix this cell information is for.

"FRI": This cell information is for FRI request.

"RTL": This cell information is for RTL request.

"ERI": This cell information is for ERI request.

- ✧ <MCC (i)>: MCC of the neighbor cell *i* (*i* is the index of the neighbor cell).
- ✧ <MNC (i)>: MNC of the neighbor cell *i*.
- ✧ <LAC (i)>: LAC in hex format of the neighbor cell *i*.
- ✧ <Cell ID (i)>: Cell ID in hex format of the neighbor cell *i*.
- ✧ <RX Level (i)>: The signal strength of the neighbor cell *i*. This parameter specifies a 6-bit value coded in 1. The dBm steps:  
 0: -110 dBm  
 1 to 62: -109 to -48 dBm  
 63: -47 dBm
- ✧ <MCC>: MCC of the serving cell.
- ✧ <MNC>: MNC of the serving cell.
- ✧ <LAC>: LAC (in hex format) of the serving cell.
- ✧ <Cell ID>: Cell ID (in hex format) of the serving cell.
- ✧ <RX Level>: The signal strength of the serving cell.

**Note:**

1. It may include information of several neighbor cells. If no neighbor cell is found, all the fields of the neighbor cell will be empty.
2. "ffff" in the fields of <LAC(i)> and <Cell ID(i)> means the terminal does not know the value.

➤ **+RESP:GTUPC,****Example:**

**+RESP:GTUPC,DE0114,015425000020117,gl500m,000,100,http://szqueclink.f3322.net:9129/gl500m/deltabin/test.ini,20191011151222,005A\$**

Parameter	Length	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
Command ID	<=3		
Result	3	100 - 103   200 - 202   300 - 302	
Download URL	<=100	Complete URL	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

- ✧ <Command ID>: The command ID in the update configuration file. It is always 0 before the device starts to update the configuration. It indicates the total number of the commands when the response result code is 301. It indicates wrong format of command ID when the response result code is 302.
- ✧ <Result>: A numeral to indicate whether the configuration is updated successfully.
  - 100: The update command is starting.
  - 101: The update command is confirmed by the device.
  - 102: The update command is refused by the device.
  - 103: The update process is refused because the battery is low.

- 200: The device starts to download the package.
- 201: The device finishes downloading the package successfully.
- 202: The device fails to download the package.
- 300: The device starts to update the device configuration.
- 301: The device finishes updating the device configuration successfully.
- 302: The device fails to update the device configuration.

✧ <Download URL>: The complete URL to download the configuration. It includes the file name.

The event report message **+RESP:GTBAA** uses the format below.

**Example:**  
**+RESP:GTBAA,DE0114,865284041222989,gl501m,2,2,0,2,003f,WTS300-1,78054101E5C1,1,320**  
**0,25.5,,0,0.0,0,433.2,114.017002,22.538826,20200116155812,0460,0000,2493,16F9,,20200117**  
**000028,021B\$**

Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	XX0000 – XXFFFF, X ∈ {'A' – 'Z', '0' – '9'}	
Unique ID	15/12	IMEI/MUID	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
Index	2	0 – 9	
Accessory Type	1	0 – 6	
Accessory Model	1	0	
Alarm Type	2	00 – FF	
Append Mask	4	0000 – FFFF	
Accessory Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
Accessory MAC	12	'0' – '9' 'A' – 'F'	
Accessory Connection Status	1	0 - 1	
Accessory Voltage	<=4	0 – 5000mV	
Accessory Temperature	<=3	-40 – 80℃	
Accessory Humidity	1	1-100	
GPS Accuracy	<=2	0	0, Last known
Speed	<=5	0.0 – 999.9 km/h	
Azimuth	<=3	0 – 359	
Altitude	<=8	(-)xxxxx.x m	
Longitude	<=11	(-)xxx.xxxxxx	

Latitude	<=10	(-)xx.xxxxxx	
GPS UTC Time	14	YYYYMMDDHHMMSS	
MCC	0 4	0XXX	
MNC	0 4	0XXX	
LAC	0 4	XXXX	
Cell ID	0 4 8	XXXXXXXX	
Reserved	0 2	00	00
Send Time	0 14	YYYYMMDDHHMMSS	
Count Number	4	0000 – FFFF	
Tail Character	1	\$	\$

- ✧ **<Index>**: The index of Bluetooth accessory in **AT+GTBAS** which triggers the **+RESP:GTBAA** message.
- ✧ **<Accessory Type>**: The type of the Bluetooth accessory which is defined in the **<Index>**. The following is supported now:
  - 0: No Bluetooth accessory.
  - 1: Reserved.
  - 2: Beacon temperature sensor.
  - 3: Reserved.
  - 5: Reserved.
  - 6: Beacon temperature & humidity sensor.
- ✧ **<Accessory Model>**: The model of the Bluetooth accessory which is defined in **AT+GTBAS**.
- ✧ **<Alarm Type>**: The alarm type of the **+RESP:GTBAA**.
  - 0: The voltage of the Bluetooth accessory is low.
  - 1: The temperature alarm: current temperature value is below low temperature limit set in **AT+GTBAS** command.
  - 2: The temperature alarm: current temperature value is upper high temperature limit set in **AT+GTBAS** command.
  - 3: The temperature alarm: current temperature value is within the range defined by temperature limits set in **AT+GTBAS** command.
  - 4: Reserved.
  - 5: Reserved.
  - 6: Reserved.
  - 7: The humidity alarm: current humidity value is below low humidity limit set in **AT+GTBAS** command.
  - 8: The humidity alarm: current humidity value is upper high humidity limit set in **AT+GTBAS** command.
  - 9: The humidity alarm: current humidity value is within the range defined by humidity limits set in **AT+GTBAS** command.
- ✧ **<Append Mask>**: Bitwise mask defined in **AT+GTBAS** to configure which data item is reported.

- Bit 0: <Accessory Name>.
  - Bit 1: <Accessory MAC>.
  - Bit 2: <Accessory Connection Status>.
  - Bit 3: <Accessory Voltage>.
  - Bit 4: <Accessory Temperature>.
  - Bit 5: <Accessory Humidity>.
- ✧ <Accessory Name>: If the Accessory name is empty, this field will be filled with one byte: 0x00.
  - ✧ <Accessory MAC>: Bluetooth accessory MAC address.
  - ✧ <Accessory Connection Status>: It indicates the connection status of Bluetooth accessory.
    - 0: Disconnected.
    - 1: Connected.
  - ✧ <Accessory Voltage>: The voltage of Bluetooth accessory.
  - ✧ <Accessory Temperature>: Temperature data of Bluetooth accessory.
  - ✧ <Accessory Humidity>: Humidity data of Bluetooth accessory.

### 3.3.5. Buffer Report

If the buffer function is enabled, the terminal will save the messages into the buffer in the following circumstances.

- ✧ No network signal.
- ✧ Failed to activate network context for the TCP or UDP connection.
- ✧ Failed to establish TCP connection with the backend server.

The buffered messages will be sent to the backend server when connection to the server recovers. The buffer reports are saved to the built-in non-volatile memory in case the device is reset. The device can save 10000 messages at most.

- ✧ Only **+RESP** messages except **+RESP:GTALC** can be buffered.
- ✧ In the buffer report, the original header string "**+RESP**" is replaced by "**+BUFF**". Other contents such as the original sending time and count number remains unchanged.
- ✧ Buffered messages will be sent only via network by TCP or UDP protocol. They cannot be sent via SMS.
- ✧ The buffered messages will be sent after the real-time messages if <Buffer Mode> in **AT+GTSRI** is set to 1.
- ✧ The buffered messages will be sent before the real-time messages if <Buffer Mode> in **AT+GTSRI** is set to 2.

#### Example:

The following is an example of the buffered message:

```
+BUFF:GTFRI,DE0114,015425000020117,gl500m,0,0,1,2,0,0,0,326.5,114.019362,22.537809,20191011075126,0460,0001,253D,AEC3,21,0,,92,0,0,28.8,20191011155127,0079$
```

### 3.4. Heartbeat

Heartbeat is used to maintain the contact between the device and the backend server via network communication. The heartbeat package is sent to the backend server at the interval

specified by *<Heartbeat Interval>* in the **AT+GTQSS** or **AT+GTSRI** command.

➤ **+ACK:GTHBD,**

Example: <b>+ACK:GTHBD,DE0114,352948070074301,,20191011155127,11F0\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

Whenever the backend server receives a heartbeat package, it should reply with an acknowledgement message to the device.

➤ **+SACK:GTHBD,**

Example: <b>+SACK:GTHBD,DE0114,11F0\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

- ✧ *<Count Number>*: The backend server uses the *<Count Number>* extracted from the heartbeat package from the device as the *<Count Number>* in the server acknowledgement of the heartbeat package.

### 3.5. Sever Acknowledgement

If server acknowledgement is enabled by the **AT+GTQSS** or **AT+GTSRI** command, the backend server should reply to the device whenever it receives a message from the device.

➤ **+SACK:**

Example: <b>+SACK:11F0\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Count Number	4	(HEX)	
Tail Character	1	\$	\$

- ✧ *<Count Number>*: The backend server uses the *<Count Number>* extracted from the received message as the *<Count Number>* in the server acknowledgement.



Queclink  
Confidential

## 4. HEX Format Message

From this version, the @Tracker protocol supports messages in HEX format. For all the commands, they still use the ASCII format as described above. By default the device uses ASCII format messages. Use **AT+GTQSS** or **AT+GTSRI** (set the *<Protocol Format>* to 1) to enable the HEX format messages.

All the messages are sorted into 5 categories (acknowledgement to command (**+ACK**), location report (**+RSP**), event report (**+EVT**), information report (**+INF**) and the heartbeat data (**+HBD**)). Messages of the same category have the same header string.

The composition of the HEX message could be customized by **AT+GTHRM** command. The actual length of each HEX report depends on the setting of the masks in **AT+GTHRM**.

The device uses CRC-CCITT (0xFFFF) method to calculate the checksum of the report data and appends the checksum to the end of the data. The backend server could use this checksum to verify the integrity of the received data.

At the end of each HEX message, the device uses 0x0D and 0x0A as the end.

The HEX messages are transmitted in network byte order (big-endian).

### 4.1. Hex Report Mask

AT+GTHRM command uses *<+ACK Mask>*, *<+RSP Mask>*, *<+EVT Mask>*, *<+INF Mask>* and *<+HBD Mask>* to control the composition of the corresponding HEX message. In each HEX message, the corresponding mask for the report is included to indicate which part is reported.

➤ **AT+GTHRM=**

Example: AT+GTHRM=gl500m,,,7F,FF7F,FF7F,FF7F,7F,,,,,0018\$			
Parameter	Length (Byte)	Range/Format	Default
Password	4 – 7	'0' – '9' 'a' – 'z' 'A' – 'Z'	gl500m
Reserved	0		
Reserved	0		
+ACK Mask	4	(HEX)	7F
+RSP Mask	4	(HEX)	FF7F
+EVT Mask	4	(HEX)	FF7F
+INF Mask	4	(HEX)	F77F

+HBD Mask	4	(HEX)	7F
Reserved	0		
Reserved	0		
Reserved	0		
Reserved	0		
Serial Number	4	(HEX)	
Tail Character	1	\$	\$

✧ <+ACK Mask>: Component mask of the acknowledgement received.

Bit	Item to Mask
Bit 7	Reserved
Bit 6	<Count Number>
Bit 5	<Send Time>
Bit 4	<Device Name>
Bit 3	<Firmware Version>
Bit 2	<Protocol Version>
Bit 1	<Device Type>
Bit 0	<Length>

✧ <+RSP Mask>: Component mask of the location message.

Bit	Item to Mask
Bit 15	<Temperature>
Bit 14	<Motion Status>
Bit 13	<Mode Selection>
Bit 12	<Battery Percentage>
Bit 11	<Network Data>
Bit 10	<Altitude>
Bit 9	<Azimuth>
Bit 8	<Speed>
Bit 7	Reserved

<b>Bit 6</b>	<Count Number>
<b>Bit 5</b>	<Send Time>
<b>Bit 4</b>	<Device Name>
<b>Bit 3</b>	<Firmware Version>
<b>Bit 2</b>	<Protocol Version>
<b>Bit 1</b>	<Device Type>
<b>Bit 0</b>	<Length>

✧ <+EVT Mask>: Component mask of the event message.

<b>Bit</b>	<b>Item to Mask</b>
<b>Bit 15</b>	<Temperature>
<b>Bit 14</b>	<Motion Status>
<b>Bit 13</b>	<Mode Selection>
<b>Bit 12</b>	<Battery Percentage>
<b>Bit 11</b>	<Network Data>
<b>Bit 10</b>	<Altitude>
<b>Bit 9</b>	<Azimuth>
<b>Bit 8</b>	<Speed>
<b>Bit 7</b>	Reserved
<b>Bit 6</b>	<Count Number>
<b>Bit 5</b>	<Send Time>
<b>Bit 4</b>	<Device Name>
<b>Bit 3</b>	<Firmware Version>
<b>Bit 2</b>	<Protocol Version>
<b>Bit 1</b>	<Device Type>
<b>Bit 0</b>	<Length>

✧ <+INF Mask>: Component mask of the information message.

<b>Bit</b>	<b>Item to Mask</b>
<b>Bit 15</b>	<Temperature>

<b>Bit 14</b>	<Motion Status>
<b>Bit 13</b>	<Mode Selection>
<b>Bit 12</b>	<Battery Percentage>
<b>Bit 11</b>	Reserved
<b>Bit 10</b>	<Hardware Version>
<b>Bit 9</b>	<CSQ RSSI> & <CSQ BER>
<b>Bit 8</b>	<ICCID>
<b>Bit 7</b>	Reserved
<b>Bit 6</b>	<Count Number>
<b>Bit 5</b>	<Send Time>
<b>Bit 4</b>	<Device Name>
<b>Bit 3</b>	<Firmware Version>
<b>Bit 2</b>	<Protocol Version>
<b>Bit 1</b>	<Device Type>
<b>Bit 0</b>	<Length>

✧ <+HBD Mask>: Component mask of the heartbeat data.

Bit	Item to Mask
<b>Bit 7</b>	Reserved
<b>Bit 6</b>	<Count Number>
<b>Bit 5</b>	<Send Time>
<b>Bit 4</b>	<Device Name>
<b>Bit 3</b>	<Firmware Version>
<b>Bit 2</b>	<Protocol Version>
<b>Bit 1</b>	<Device Type>
<b>Bit 0</b>	<Length>

The acknowledgment message of **AT+GTHRM** command:

➤ **+ACK:GTHRM,**

**Example:**

+ACK:GTHRM,FE1001,862170019025640,,0019,20140511093254,11F0\$			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

## 4.2. Acknowledgement +ACK

### ➤ +ACK,

#### Example:

2B 41 43 4B 00 00 7F 25 DE 01 13 02 03 67 6C 35 30 30 6D 00 00 00 03 09 07 E3 0C 13 09 23 08 02 64 67 6E 0D 0A

Parameter	Length (Byte)	Range/Format	Default
Message Header	4	+ACK	+ACK
Message Type	1		
Report Mask	2	(HEX)	
Length	1		
Device Type	1	DE	DE
Protocol Version	2	(HEX)	010F
Firmware Version	2	(HEX)	
Unique ID	8	(IMEI)	
ID	1		
Serial Number	2	(HEX)	
Send Time	7	YYYYMMDDHHMMSS	
Count Number	2	(HEX)	
Checksum	2	(HEX)	
Tail Characters	2	0x0D 0x0A	0x0D 0x0A

✧ <Message Type>: The ID of the command that the device received.

Command	ID
AT+GTBSI	0
AT+GTSRI	1
AT+GTQSS	2
Reserved	3
AT+GTCFG	4
AT+GTPIN	5
AT+GTDG	6
AT+GTTMA	7
AT+GTNMD	8
AT+GTPDS	9
AT+GTGEO	10
AT+GTTEM	11
AT+GTLA	12
AT+GTLTA	13
Reserved	14
AT+GTRTO	15
AT+GTUPC	16
AT+GTWLT	17
AT+GTUPD	18
AT+GTHRM	19
AT+GTBTS	20
AT+GTBAS	21

- ✧ <Report Mask>: It refers to the <+ACK Mask> in **AT+GTHRM**.
- ✧ <Length>: The length of the acknowledgement message (total characters from header to the tail).
- ✧ <Unique ID>: If Bit 4 of <+ACK Mask> is 0, IMEI of the device will be used as the unique ID of the device. IMEI is a 15-digit string. In the HEX format message, every 2 digits are encoded into one byte as an integer.

IMEI	13	57	90	24	68	11	22	0
HEX	0D	39	5A	18	44	0B	16	00

If the Bit 4 of <+ACK Mask> is 1, the device name is used as the unique ID of the device. Refer to the <Device Name> in **AT+GTCFG** for the device name. Device name is an 8-bytes

string. If the length of the <Device Name> is more than 8 bytes, only the first 8 bytes will be acquired. In the Hex format message, each byte is encoded into one byte as an integer. If the device name is less than 8 bytes, the empty bytes will be set to 0.

Device Name	g	v	5	0	l	t	m	
HEX	67	76	35	30	6C	74	6D	00

- ✧ <ID>: Sub-command ID of **AT+GTRTO** or **AT+GTGEO**. Set it to 0 for other reports.
- ✧ <Send Time>: The local time to send the acknowledgement message. Total 7 bytes. The first 2 bytes are for year, the rest 5 bytes for month, day, hour, minute and second respectively.

Send Time	2011		01	31	06	29	11
HEX	07	DB	01	1F	06	1D	0B

- ✧ <Checksum>: The CRC16 checksum for data from <Message Type> to <Count Number>.

### 4.3. Location Report +RSP

Location messages (including **+RESP:GTGEO**, **+RESP:GTFRI**, **+RESP:GTRTL**, **+RESP:GTNMR**, **+RESP:GTDG**) use this format.

#### ➤ +RSP,

##### Example:

2B 52 53 50 00 FF 7F 4E DE 01 13 02 03 67 6C 35 30 30 6D 00 00 01 00 05 00 00 03 00 00 00 72 06  
CB BC 99 01 57 E4 07 07 E3 0C 13 02 01 36 01 CC 00 01 25 3D 00 00 AE C3 16 00 00 42 01 01 00  
1C 01 07 E3 0C 13 0A 01 33 02 8F 9F 7F 0D 0A

Parameter	Length (Byte)	Range/Format	Default
Message Header	4	+RSP	+RSP
Message Type	1		
Report Mask	2	(HEX)	
Length	1		
Device Type	1	DE	DE
Protocol Version	2	(HEX)	
Firmware Version	2	(HEX)	
Unique ID	8	(IMEI)	
Report Id	1	0 – 4	
Report Type	1		
GPS Accuracy	1	0 – 6	
Speed	3	0.0 – 999.9(km/h)	



Azimuth	2	0 – 359	
Altitude	2		
Longitude	4		
Latitude	4		
GPS UTC Time	7	YYYYMMDDHHMMSS	
MCC	2	000 – 999	
MNC	2	000 – 999	
LAC	2	(HEX)	
Cell ID	4	(HEX)	
CSQ RSSI	1	0 - 31 99	
CSQ BER	1	0 - 7 99	
Reserved	1		
Battery Percentage	1	0 - 100	
Mode Selection	1	0 1	
Movement Status	1	0 1	
Temperature	3	(-)XX.X	
Send Time	7	YYYYMMDDHHMMSS	
Count Number	2	(HEX)	
Checksum	2	(HEX)	
Tail Characters	2	0x0D 0x0A	0x0D 0x0A

✧ <Message Type>: The ID of location message.

Command	ID
<b>+RESP:GTGEO</b>	0
<b>+RESP:GTFRI</b>	1
<b>+RESP:GTPNL</b>	2
<b>+RESP:GTNMR</b>	3
<b>+RESP:GTRTL</b>	4
<b>+RESP:GTDGOG</b>	5
<b>+RESP:GTERI</b>	6
<b>+RESP:GTLBC</b>	7

<b>+RESP:GTSOS</b>	8
--------------------	---

- ✧ **<Report Mask>**: It refer to the **<+RSP Mask>** in **AT+GTHRM**.
- ✧ **<Unique ID>**: If the Bit 4 of **<+RSP Mask>** is 0, IMEI of the device is used as the unique ID of the device. IMEI is a 15-digit string. In the HEX format message, every 2 digits are encoded into one byte as an integer.

<b>IMEI</b>	<b>13</b>	<b>57</b>	<b>90</b>	<b>24</b>	<b>68</b>	<b>11</b>	<b>22</b>	<b>0</b>
<b>HEX</b>	<b>0D</b>	<b>39</b>	<b>5A</b>	<b>18</b>	<b>44</b>	<b>0B</b>	<b>16</b>	<b>00</b>

If the Bit 6 of **<+RSP Mask>** is 1, the device name is used as the unique ID of the device.

Refer to the **<Device Name>** in **AT+GTCFG** for the device name. Device name is an 8-byte string. If the length of the **<Device Name>** is more than 8 bytes, only the first 8 bytes will be acquired. In the Hex format message, each byte is encoded into one byte as an integer. If the device name is less than 8 bytes, the empty bytes will be set to 0.

<b>Device Name</b>	<b>g</b>	<b>v</b>	<b>5</b>	<b>0</b>	<b>l</b>	<b>t</b>	<b>m</b>	
<b>HEX</b>	<b>67</b>	<b>76</b>	<b>35</b>	<b>30</b>	<b>6C</b>	<b>74</b>	<b>6D</b>	<b>00</b>

- ✧ **<Report ID>**: The ID of Geo-fence in **+RESP:GTGEO**. For the ID of other reports, it is 0.
- ✧ **<Report Type>**: The type of the messages **+RESP:GTGEO**, **+RESP:GTDOG** and **+RESP:GTNMR**. For other reports, it is 0.
  - For **+RESP:GTGEO**
    - 0: Exit the corresponding Geo-fence
    - 1: Enter the corresponding Geo-fence
  - For **+RESP:GTNMR**
    - 0: The state of the device changed from motion to rest
    - 1: The state of the device changed from rest to motion
  - For **+RESP:GTDOG**
    - 0: Reboot periodically according to the **<Interval>** and **<Time>** settings
- ✧ **<Speed>**: Total 3 bytes. The first two bytes are for the integer part of the speed and the last byte is for the fraction part. The fraction part has only 1 digit.
- ✧ **<Longitude>**: The longitude of the current position. Total 4 bytes. The longitude is converted to an integer with 6 implicit decimals and this integer is reported in HEX format. If the value of the longitude is negative, it is represented in 2's complement format.

<b>Longitude</b>	<b>121390847</b>			
<b>121.390847</b>				
<b>HEX</b>	<b>07</b>	<b>3C</b>	<b>46</b>	<b>FF</b>

- ✧ **<Latitude>**: The latitude of the current position. Total 4 bytes. The latitude is converted to an integer with 6 implicit decimals and this integer is reported in HEX format. If the value of the latitude is negative, it is represented in 2's complement format.

<b>Latitude</b>	<b>31164503</b>			
<b>31.164503</b>				
<b>HEX</b>	<b>01</b>	<b>DB</b>	<b>88</b>	<b>57</b>

- ✧ **<GPS UTC Time>**: The UTC time from the GPS chip. Total 7 bytes. The first 2 bytes are for year, the rest 5 bytes for month, day, hour, minute and second respectively.

<b>GPS UTC Time</b>	<b>2011</b>	<b>07</b>	<b>14</b>	<b>08</b>	<b>24</b>	<b>13</b>
<b>HEX</b>	<b>07</b>	<b>DB</b>	<b>07</b>	<b>0E</b>	<b>08</b>	<b>0D</b>

- ✧ **<Mode Selection>**: Current mode of the device. Total 1 byte.
- 0: Power saving mode (PSM)
  - 1: Continuous mode
- ✧ **<Movement Status>**: The movement status of the device. Total 1 byte. It must be noted that the sensor function must be enabled in the **AT+GTNMD** command, otherwise it's always 0.
- 0: Stillness
  - 1: Motion
- ✧ **<Temperature>**: Total 3 bytes. The first two bytes are for the integer part of the temperature and the last byte is for the fraction part. The fraction part has only 1 digit. It must be noted that the temperature function must be enabled in the in the **AT+GTTEM** command, otherwise it's always 0.

Location message for **+RESP:GTERI** uses below format.

➤ **+RSP,**

**Example: 2B 52 53 50 01 FF 7F 4E DE 01 13 02 03 67 6C 35 30 30 6D 00 00 00 00 05 00 00 00 00 00 6E 06 CB BC D5 01 57 E3 AD 07 E3 0C 13 02 0D 15 01 CC 00 01 25 3D 00 00 AE C3 17 00 00 41 01 00 00 1B 00 07 E3 0C 13 0A 0D 1F 02 A5 01 F6 0D 0A**

Parameter	Length (Byte)	Range/Format	Default
Message Header	4	+RSP	+RSP
Message Type	1		
Report Mask	2	(HEX)	
Length	2		
Device Type	1	DE	DE
Protocol Version	2	(HEX)	
Firmware Version	2	(HEX)	
Unique ID	8	(IMEI)	
Report Id	1	0 – 4	
Report Type	1		
GPS Accuracy	1	0 – 6	
Speed	3	0.0 – 999.9(km/h)	
Azimuth	2	0 – 359	

Altitude	2		
Longitude	4		
Latitude	4		
GPS UTC Time	7	YYYYMMDDHHMMSS	
MCC	2	000 – 999	
MNC	2	000 – 999	
LAC	2	(HEX)	
Cell ID	4	(HEX)	
CSQ RSSI	1	0 - 31 99	
CSQ BER	1	0 - 7 99	
Reserved	1		
Battery Percentage	1	0 - 100	
Mode Selection	1	0 1	
Movement Status	1	0 1	
Bluetooth Accessory Number	1	0 – 10	
Index	1	0 – 9	
Accessory Type	1	0 - 1	
Accessory Model	1	0	
Raw Data Length	1	0 - FF	
Raw Data			
Accessory Append Mask	2	0 - FFFF	
Accessory Name	<=21		
Accessory MAC	6	000000000000 FFFFFFFFFFFF	-
Accessory Connection Status	1	0 - 1	
Accessory Voltage	2	0 – 5000mV	
Accessory Temperature	1	-40 – 80 °C	
Accessory Humidity	1	0-100	
Send Time	7	YYYYMMDDHHMMSS	
Count Number	2	(HEX)	

Checksum	2	(HEX)	
Tail Characters	2	0x0D 0x0A	0x0D 0x0A

- ✧ **<Bluetooth Accessory Number>**: The number of Bluetooth accessory. If it is 0, the accessory details fields from **<Index>** to **<Accessory Humidity>** will not display. If there are more than one Bluetooth accessory, the **+GTERI** report will repeat from “Index” to “Accessory Humidity” to show the information of all devices.
- ✧ **<Index>**: The index of Bluetooth accessory defined in **AT+GTBAS** which triggers the **+RESP:GTBAA** message.
- ✧ **<Accessory Type>**: The type of the Bluetooth accessory which is defined in **AT+GTBAS**.
- ✧ **<Accessory Model>**: The model of the Bluetooth accessory which is defined in **AT+GTBAS**.
- ✧ **<Raw Data Length>**: It indicates the length of **<Raw Data>**.
- ✧ **<Raw Data>**: The data is read from Bluetooth accessory. It varies depending on **<Accessory Type>** and **<Accessory Model>**.
- ✧ **<Append Mask>**: Bitwise mask defined in **AT+GTBAS** to configure which data item is reported.
- ✧ **<Accessory Name>**: The name of the Bluetooth accessory. It ends with 0x00.
- ✧ **<Accessory MAC>**: The MAC address of the Bluetooth accessory.
- ✧ **<Accessory Connection Status>**: It indicates the connection status of Bluetooth accessory.
  - 0: Disconnected.
  - 1: Connected.
- ✧ **<Accessory Voltage>**: The voltage of Bluetooth accessory.
- ✧ **<Accessory Temperature>**: Temperature data of Bluetooth accessory.

**Note:** The key word (optional) means the item is controlled by the parameter **<ERI Mask>**.

Location message for **+RESP:GTLBC** uses below format.

**Example:**

2B 52 53 50 07 FF 3F 51 DE 01 14 10 02 67 6C 35 30 30 6D 00 00 60 15 88 95 70 95 6F 01 00 00 00  
00 00 01 05 06 CB BB 2F 01 57 E3 68 07 E4 01 06 09 07 21 01 CC 00 01 25 3D 00 00 AE C3 13 00  
00 49 01 00 00 19 02 07 E4 01 06 11 07 22 50 A3 0D 0A

Parameter	Length (Byte)	Range/Format	Default
Message Header	4	+RSP	+RSP
Message Type	1		
Report Mask	2	(HEX)	
Length	1		
Device Type	1	EE	EE
Protocol Version	2	(HEX)	
Firmware Version	2	(HEX)	
Unique ID	8	(IMEI)	

Number Length/Number Type	1		
Phone Number	<=10		
GPS Accuracy	1	0 – 50	
Speed	3	0.0 – 999.9(km/h)	
Azimuth	2	0 – 359	
Altitude	2		
Longitude	4		
Latitude	4		
GPS UTC Time	7	YYYYMMDDHHMMSS	
MCC	2	000 – 999	
MNC	2	000 – 999	
LAC	2	(HEX)	
Cell ID	4	(HEX)	
CSQ RSSI	1	0 - 31 99	
CSQ BER	1	0 - 7 99	
Reserved	1		
Battery Percentage	1	0 - 100	
Mode Selection	1	0 1	
Movement Status	1	0 1	
Temperature	3	+/-XX.X	
Send Time	7	YYYYMMDDHHMMSS	
Count Number	2	(HEX)	
Checksum	2	(HEX)	
Tail Characters	2	0x0D 0x0A	0x0D 0x0A

- ✧ <Number Length/Number Type>: The high nibble is for <Number Length> and the low nibble is for <Number Type>. <Number Length> is the number of bytes used to represent the phone number. <Number Type> indicates if there is a '+' sign before the phone number. 1 means there is the sign and 0 means no such a sign.

	Number Length	Number Type
HEX	7	0

- ✧ <Phone Number>: No more than 10 bytes. Each byte uses the high nibble and low nibble to

represent one digit of the phone number respectively. If the last low nibble has no digit to represent, fill in 0xF.

Phone Number	02	15	44	50	29	3
02154450293						
HEX	02	15	44	50	29	3F

#### 4.4. Information Report +INF

Information messages include **+RESP:GTINF**. The message uses the format as below.

➤ **+INF,**

**Example:**

2B 49 4E 46 00 F7 7F 32 DE 01 13 02 03 67 6C 35 30 30 6D 00 00 01 03 89 86 01 17 85 10 23 14  
51 36 16 00 00 00 07 E3 0C 13 0D 2B 10 03 6E E4 62 0D 0A

Parameter	Length (Byte)	Range/Format	Default
Message Header	4	+INF	+INF
Reserved	1	0	
Report Mask	2	(HEX)	
Length	1		
Device Type	1	DE	DE
Protocol Version	2	(HEX)	
Firmware Version	2	(HEX)	
Unique ID	8	(IMEI)	
Hardware Version	2	(HEX)	
ICCID	10	ICCID	
CSQ RSSI	1	0 – 31   99	
CSQ BER	1	0 – 7   99	
Reserved	2	0000	
Send Time	7	YYYYMMDDHHMMSS	
Count Number	2	(HEX)	
Checksum	2	(HEX)	
Tail Characters	2	0x0D 0x0A	0x0D 0x0A

✧ **<Report Mask>**: It refers to the **<+INF Mask>** in **AT+GTHRM**.

- ✧ **<Unique ID>**: If the Bit 4 of **<+INF Mask>** is 0, IMEI of the device is used as the unique ID. IMEI has 14 bytes in hexadecimal format. In the Hex format message, every two bytes are encoded into one byte as an integer. The 8th byte is reserved and its value is 0x00.

IMEI	13	57	90	24	68	11	22	0
HEX	0D	39	5A	18	44	0B	16	00

If the Bit 1 of **<+INF Mask>** is 1, the device name is used as the unique ID of the device. Refer to the **<Device Name>** in **AT+GTCFG** for the device name. Device name is an 8-byte string. If the length of the **<Device Name>** is more than 8 bytes, only the first 8 bytes will be acquired. In the Hex format report, each byte is encoded into one byte as an integer. If the device name is less than 8 bytes, the empty bytes will be set to 0.

Device Name	g	v	5	0	l	t	m	
HEX	67	76	35	30	6C	74	6D	00

- ✧ **<ICCID>**: ICCID is a 20-digit string. In the HEX format message, every 4 bits are used to represent one digit of the ICCID.

ICCID	89	86	00	00	09	09	17	21	49	53
HEX	89	86	00	00	09	09	17	21	49	53

- ✧ **<Cell Number>**: It represents the number of the IMSI. The IMSI consists of MCC, MNC, LAC, and Cell ID.

#### 4.5. Event Report +EVT

Event message **+RESP:GTPNA** uses this format.

➤ **+EVT,**

**Example:**

**2B 45 56 54 00 FF 7F 23 DE 01 13 02 03 67 6C 35 30 30 6D 00 00 05 07 E3 0C 13 0D 39 2C 03 8D 3D 0D 0D 0A**

Parameter	Length (Byte)	Range/Format	Default
Message Header	4	+EVT	+EVT
Message Type	1		
Report Mask	2	(HEX)	
Length	1		
Device Type	1	DE	DE
Protocol Version	2	(HEX)	
Firmware Version	2	(HEX)	
Unique ID	8	(IMEI)	
Power On Type	1	1 - 9	
Send Time	7	YYYYMMDDHHMMSS	



Count Number	2	(HEX)	
Checksum	2	(HEX)	
Tail Characters	2	0x0D 0x0A	0x0D 0x0A

✧ <Message Type>: The ID of event message.

Command	ID
+RESP:GTPNA	0
+RESP:GTPFA	1
+RESP:GTBPL	2
+RESP:GTTEM	3
Reserved	4
+RESP:GTUPC	5
+RESP:GTLTA	6
+RESP:GTLTA	7
+RESP:GTUPD	8
+RESP:GTSTC	9
+RESP:GTBTC	10
+RESP:GTBAA	11

✧ <Report Mask>: It refers to the <+EVT Mask> in **AT+GTHRM**.

✧ <Unique ID>: If the Bit 4 of <+EVT Mask> is 0, IMEI of the device is used as the unique ID of the device. IMEI is a 15-digit string. In the HEX format message, every 2 digits are encoded into one byte as an integer.

IMEI	13	57	90	24	68	11	22	0
HEX	0D	39	5A	18	44	0B	16	00

If the Bit 6 of <+EVT Mask> is 1, the device name is used as the unique ID of the device. Refer to the <Device Name> in **AT+GTCFG** for the device name. Device name is an 8-byte string. If the length of the <Device Name> is more than 8 bytes, only the first 8 bytes will be acquired. In the Hex format report, each byte is encoded into one byte as an integer. If the device name is less than 8 bytes, the empty bytes will be set to 0.

Device Name	g	v	5	0	l	t	m	
HEX	67	76	35	30	6C	74	6D	00

✧ <Power On Type>: A numeral to indicate how the terminal is activated.

- 1: Movement detected by the terminal.
- 2: Specified time reached.
- 3: Light sensor alarm event.

- 4: Manual powering on for the first time.
- 5: RTO command or dog reboot.
- 6: Reserved
- 7: RTC error.
- 8: FOTA process.
- 9: Temperature sensor alarm event.

Event message **+RESP:GTPFA** uses this format.

➤ **+EVT,**

Example:			
2B 45 56 54 01 FF 7F 22 DE 01 13 02 03 67 6C 35 30 30 6D 00 00 07 E3 0C 13 0D 33 23 03 81 71 DD 0D 0A			
Parameter	Length (Byte)	Range/Format	Default
Message Header	4	+EVT	+EVT
Message Type	1		
Report Mask	2	(HEX)	
Length	1		
Device Type	1	DE	DE
Protocol Version	2	(HEX)	
Firmware Version	2	(HEX)	
Unique ID	8	(IMEI)	
Send Time	7	YYYYMMDDHHMMSS	
Count Number	2	(HEX)	
Checksum	2	(HEX)	
Tail Characters	2	0x0D 0x0A	0x0D 0x0A

Event messages **+RESP:GTSTC**, **+RESP:GTBTC** use this format.

➤ **+EVT,**

Example:			
2B 45 56 54 09 FF 7F 23 DE 01 13 02 03 67 6C 35 30 30 6D 00 00 44 07 E3 0C 13 0E 04 33 03 A6 9F E2 0D 0A			
Parameter	Length (Byte)	Range/Format	Default
Message Header	4	+EVT	+EVT
Message Type	1		
Report Mask	2	(HEX)	

Length	1		
Device Type	1	DE	DE
Protocol Version	2	(HEX)	
Firmware Version	2	(HEX)	
Unique ID	8	(IMEI)	
Battery Percentage	1	0 - 100	
Send Time	7	YYYYMMDDHHMMSS	
Count Number	2	(HEX)	
Checksum	2	(HEX)	
Tail Characters	2	0x0D 0x0A	0x0D 0x0A

Event messages **+RESP:GTBPL**, **+RESP:GTTEM**, **+RESP:GTLTA** use this format.

➤ **+EVT**,

<b>Example:</b> 2B 45 56 54 02 FF 7F 4E DE 01 10 08 03 67 6C 35 30 30 6D 00 00 00 00 02 00 00 00 00 00 00 5F 06 CB BC D8 01 57 E3 99 07 E3 08 07 02 23 17 01 CC 00 01 25 3D 00 00 AE C3 0F 00 00 09 00 00 00 00 00 07 E3 08 07 0A 23 18 01 05 D3 07 0D 0A			
Parameter	Length (Byte)	Range/Format	Default
Message Header	4	+EVT	+EVT
Message Type	1		
Report Mask	2	(HEX)	
Length	1		
Device Type	1	DE	DE
Protocol Version	2	(HEX)	
Firmware Version	2	(HEX)	
Unique ID	8	(IMEI)	
Event State1	1	0-4	
Event State2	1	0	
GPS Accuracy	1	0 – 6	0
Speed	3	0.0 – 999.9(km/h)	
Azimuth	2	0 – 359	
Altitude	2		

Longitude	4		
Latitude	4		
GPS UTC Time	7	YYYYMMDDHHMMSS	
MCC	2	000 –999	
MNC	2	000 – 999	
LAC	2	(HEX)	
Cell ID	4	(HEX)	
CSQ RSSI	1	0 - 31 99	
CSQ BER	1	0 - 7 99	
Reserved	1		
Battery Percentage	1	0 - 100	
Mode Selection	1	0 1	
Movement Status	1	0 1	
Temperature	3	(-)XX.X	
Send Time	7	YYYYMMDDHHMMSS	
Count Number	2	(HEX)	
Checksum	2	(HEX)	
Tail Characters	2	0x0D 0x0A	0x0D 0x0A

#### For +RESP:GTBPL

✧ <Event state1>: 0

✧ <Event state2>: 0

#### For +RESP:GTTEM

✧ <Event state1>: The temperature alarm state

- 1: The current temperature is lower than the low temperature threshold specified by <Min. Temperature>.
- 2: The current temperature is higher than the high temperature threshold specified by <Max. Temperature>.
- 3: The current temperature is within the temperature threshold range.
- 4: The current temperature is outside the temperature threshold range.

✧ <Event state2>: 0

#### For +RESP:GTLTA

✧ <Event state1>: The light sensor tamper state.

- 0: Normal state
- 1: Tamper alarm state

✧ <Event state2>: 0

Event message **+RESP:GTLA** uses this format.

➤ **+EVT,**

**Example:**

2B 45 56 54 06 FF 7F 4E DE 01 13 02 03 67 6C 35 30 30 6D 00 00 01 00 03 00 00 00 00 00 FF F8 06  
CB BA F3 01 57 E2 11 07 E3 0C 13 05 3A 20 01 CC 00 01 25 3D 00 00 AE C3 00 00 09 44 01 01 00  
1E 05 07 E3 0C 13 0D 3A 21 03 92 3A 42 0D 0A

Parameter	Length (Byte)	Range/Format	Default
Message Header	4	+EVT	+EVT
Message Type	1		
Report Mask	2	(HEX)	
Length	1		
Device Type	1	DE	DE
Protocol Version	2	(HEX)	
Firmware Version	2	(HEX)	
Unique ID	8	(IMEI)	
Event State1	1	0-4	
Event State2	1	0	
GPS Accuracy	1	0 – 6	0
Speed	3	0.0 – 999.9(km/h)	
Azimuth	2	0 – 359	
Altitude	2		
Longitude	4		
Latitude	4		
GPS UTC Time	7	YYYYMMDDHHMMSS	
MCC	2	000 – 999	
MNC	2	000 – 999	
LAC	2	(HEX)	
Cell ID	4	(HEX)	
CSQ RSSI	1	0 - 31 99	
CSQ BER	1	0 - 7 99	
Light level	1	0 - 9	00

Battery Percentage	1	0 - 100	
Mode Selection	1	0 1	
Movement Status	1	0 1	
Temperature	3	(-)XX.X	
Send Time	7	YYYYMMDDHHMMSS	
Count Number	2	(HEX)	
Checksum	2	(HEX)	
Tail Characters	2	0x0D 0x0A	0x0D 0x0A

For **+RESP:GTLSA**

- ✧ <Event state1>: The light sensor alarm state.
  - 0: Normal state
  - 1: Above threshold alarm state
  - 2: Below threshold alarm state
- ✧ <Event state2>: 0
- ✧ <Light Level>: The level of light intensity detected by the device.

Event message **+RESP:GTUPC** uses this format.

<b>Example:</b> <b>2B 45 56 54 05 FF 7F 5F DE 01 13 02 03 67 6C 35 30 30 6D 00 00 01 01 2D 39 68 74 74 70 3A 2F 2F 73 7A 71 75 65 63 6C 69 6E 6B 2E 66 33 33 32 32 2E 6E 65 74 3A 39 31 32 39 2F 47 4C 35 30 31 4D 2F 64 65 6C 74 61 62 69 6E 2F 74 65 73 74 2E 69 6E 69 07 E3 0C 13 0E 01 2C 03 9C B1 7C 0D 0A</b>			
Parameter	Length (Byte)	Range/Format	Default
Message Header	4	+EVT	+EVT
Message Type	1		
Report Mask	2	(HEX)	
Length	1		
Device Type	1	DE	DE
Protocol Version	2	(HEX)	
Firmware Version	2	(HEX)	
Unique ID	8	(IMEI)	
Command ID	1		
Result	2	100 - 103 200 - 202 300 - 302	
URL Length	1		

Download URL	<=60	Complete URL	1
Send Time	7	YYYYMMDDHHMMSS	
Count Number	2	(HEX)	
Checksum	2	(HEX)	
Tail Characters	2	0x0D 0x0A	0x0D 0x0A

- ✧ **<Command ID>**: The command ID in the update configuration file. It is always 0 before the device starts to update the configuration. It indicates the total number of the successfully executed commands when the result code is 301. And it is the number of the commands which have failed to execute when the result code is 302.
- ✧ **<Result>**: A numeral to indicate whether the configuration is updated successfully.
  - 100: The update command is starting.
  - 101: The update command is confirmed by the device.
  - 102: The update command is refused by the device.
  - 103: The update process is refused because the battery is low.
  - 200: The device starts to download the package.
  - 201: The device finishes downloading the package successfully.
  - 202: The device fails to download the package.
  - 300: The device starts to update the device configuration.
  - 301: The device finishes updating the device configuration successfully.
  - 302: The device fails to update the device configuration.
- ✧ **<URL Length>**: The length of complete URL.
- ✧ **<Download URL>**: The complete URL to download the configuration. It includes the file name.

Event message **+RESP:GTUPD** uses this format.

➤ **+EVT,**

**Example:**

2B 41 43 4B 12 00 7F 25 DE 01 13 02 03 67 6C 35 30 30 6D 00 00 00 00 01 07 E3 0C 13 0E 06 03 03 A7 9D 8D 0D 0A

Parameter	Length (Byte)	Range/Format	Default
Message Header	4	+EVT	+EVT
Message Type	1		
Report Mask	2	(HEX)	
Length	1		
Device Type	1	DE	DE
Protocol Version	2	(HEX)	
Firmware Version	2	(HEX)	

Unique ID	8	(IMEI)	
Code	2		
Retry	1		
Send Time	7	YYYYMMDDHHMMSS	
Count Number	2	(HEX)	
Checksum	2	(HEX)	
Tail Characters	2	0x0D 0x0A	0x0D 0x0A

The event report message **+RESP:GTBAA** uses the format below.

➤ **+EVT,**

<b>Example:</b> <b>2B 45 56 54 0B FF 7F 5E DE 01 13 02 03 67 6C 35 30 30 6D 00 00 03 02 00 02 00 3F 57 54 53 33</b> <b>30 30 2D 32 00 78 05 41 CF B8 01 01 08 E6 19 00 00 00 00 00 00 00 00 8A 06 CB BD 40 01 57 E4</b> <b>94 07 E3 0C 13 06 03 1B 01 CC 00 01 25 3D 00 00 AE C3 00 07 E3 0C 13 0E 03 39 03 A3 A3 D1 0D</b> <b>0A</b>			
Parameter	Length (byte)	Range/Format	Default
Message Header	4	+EVT	+EVT
Message Type	1		
Report Mask	2	(HEX)	
Length	1		
Device Type	1	DE	DE
Protocol Version	2	(HEX)	
Firmware Version	2	(HEX)	
Unique ID	8	(IMEI)	
Index	1	0 – 9	
Accessory Type	1	0 – 6	
Accessory Model/Beacon ID Accessory Model	1	0	
Alarm Type	1	00 – FF	
Append Mask	2	0000– FFFF	
Accessory Name	<=21	'0' – '9' 'a' – 'z' 'A' – 'Z' ' ' ' _'	



Accessory MAC	6	'0' – '9' 'A' – 'F'	
Accessory Connection Status	1	0 - 1	
Accessory Voltage	2	0 – 5000mV	
Accessory Temperature	1	-40 – 80℃	
Accessory Humidity	1	1-100	
GPS Accuracy	1	0 – 6	0
Speed	3	0.0 – 999.9(km/h)	
Azimuth	2	0 – 359	
Altitude	2		
Longitude	4		
Latitude	4		
GPS UTC Time	7	YYYYMMDDHHMMSS	
MCC	2	000 – 999	
MNC	2	000 – 999	
LAC	2	(HEX)	
Cell ID	4	(HEX)	
Reserved	1		
Send Time	7	YYYYMMDDHHMMSS	
Count Number	2	0000 – FFFF	
Checksum	2	0000 – FFFF	
Tail Characters	2	0x0D 0x0A	0x0D 0x0A

- ✧ **<Index>**: The index of Bluetooth accessory in AT+GTBAS which triggers the +RESP:GTBAA message.
- ✧ **<Accessory Type>**: The type of the Bluetooth accessory which is defined in the <Index>. The following is supported now:
  - 0: No Bluetooth accessory.
  - 1: Reserved.
  - 2: Beacon temperature sensor.
  - 3: Reserved.
  - 5: Reserved.
  - 6: Beacon Temperature & humidity sensor.
- ✧ **<Accessory Model>**: The model of the Bluetooth accessory which is defined in **AT+GTBAS**.
- ✧ **<Alarm Type>**: The alarm type of the **+RESP:GTBAA**.
  - 0: The voltage of the Bluetooth accessory is low.

- 1: The temperature alarm: current temperature value is below low temperature limit set in **AT+GTBAS** command.
  - 2: The temperature alarm: current temperature value is upper high temperature limit set in **AT+GTBAS** command.
  - 3: The temperature alarm: current temperature value is within the range defined by temperature limits set in **AT+GTBAS** command.
  - 4. Reserved.
  - 5. Reserved.
  - 6. Reserved.
  - 7: The humidity alarm: current humidity value is below low humidity limit set in **AT+GTBAS** command.
  - 8: The humidity alarm: current humidity value is upper high humidity limit set in **AT+GTBAS** command.
  - 9: The humidity alarm: current humidity value is within the range defined by humidity limits set in **AT+GTBAS** command.
- ✧ **<Append Mask>**: Bitwise mask defined in **AT+GTBAS** to configure which data item is reported.
- Bit 0: **<Accessory Name>**.
  - Bit 1: **<Accessory MAC>**.
  - Bit 2: **<Accessory Connection Status>**.
  - Bit 3: **<Accessory Voltage>**.
  - Bit 4: **<Accessory Temperature>**.
  - **Bit 5: <Accessory Humidity>**.
- ✧ **<Accessory Name>**: If the Accessory name is empty, this field will be filled with one byte: 0x00.
- ✧ **<Accessory MAC>**: Bluetooth accessory MAC address.
- ✧ **<Accessory Connection Status>**: It indicates the connection status of Bluetooth accessory.
- 0: Disconnected.
  - 1: Connected.
- ✧ **<Accessory Voltage>**: The voltage of Bluetooth accessory.
- ✧ **<Accessory Temperature>**: Temperature data of Bluetooth accessory.
- ✧ **<Accessory Humidity>**: Humidity data of Bluetooth accessory.

#### 4.6. Heartbeat Data +HBD

➤ **+HBD,**

<b>Example:</b> <b>2B 48 42 44 00 00 7F 22 DE 01 13 02 03 67 6C 35 30 30 6D 00 00 07 E3 0C 13 0E 36 11 00 38 1F FC 0D 0A</b>			
Parameter	Length (Byte)	Range/Format	Default
Message Header	4	+HBD	+HBD
Reserved	1	0	
Report Mask	2	(HEX)	

Length	1		
Device Type	1	DE	DE
Protocol Version	2	(HEX)	
Firmware Version	2	(HEX)	
Unique ID	8	(IMEI)	
Send Time	7	YYYYMMDDHHMMSS	
Count Number	2	(HEX)	
Checksum	2	(HEX)	
Tail Characters	2	0x0D 0x0A	0x0D 0x0A

- ✧ **<Report Mask>**: It refers to the **<+HBD Mask>** in **AT+GTHRM**.
- ✧ **<Unique ID>**: If Bit 4 of **<+HBD Mask>** is 0, IMEI of the device is used as the unique ID of the device. IMEI is a 15-digit string. In the HEX format message, every 2 digits are encoded into one byte as an integer.

IMEI	13	57	90	24	68	11	22	0
HEX	0D	39	5A	18	44	0B	16	00

If the Bit 4 of **<+HBD Mask>** is 1, the device name is used as the unique ID of the device. Refer to the **<Device Name>** in **AT+GTCFG** for the device name. Device name is an 8-byte string. If the length of the **<Device Name>** is more than 8 bytes, only the first 8 bytes will be acquired. In the Hex format report, each byte is encoded into one byte as an integer. If the device name is less than 8 bytes, the empty bytes will be set to 0.

Device Name	g	v	5	0	l	t	m	
HEX	67	76	35	30	6C	74	6D	00

If the mask of **<UID>** is set to 0 in the **<+HBD Mask>** of **AT+GTHRM**, the heartbeat message will not include device name or IMEI information. If the mask of **<UID>** is set to 1, the heartbeat message will report device name or IMEI according to the mask of **<Device Name>**.

#### 4.7. Buffer Report in HEX Format

When HEX format messages go into the local buffer, the device will replace the second byte of the messages with 'B'. Thus, **+BSP** is buffered report for **+RSP**, **+BNF** is buffered report for **+INF** and **+BVT** is buffered report for **+EVT**. The rest part of the messages is the same.



Queclink  
Confidential

## 5. Appendix: Message Index

### ✧ Command and ACK

AT+GTBSI

+ACK:GTBSI

AT+GTSRI

+ACK:GTSRI

AT+GTQSS

+ACK:GTQSS

AT+GTCFG

+ACK:GTCFG

AT+GTPIN

+ACK:GTPIN

AT+GTDog

+ACK:GTDog

AT+GTTMA

+ACK:GTTMA

AT+GTNMD

+ACK:GTNMD

AT+GTFRI

+ACK:GTFRI

AT+GTGEO

+ACK:GTGEO

AT+GTTEM

+ACK:GTTEM

AT+GTRTO

+ACK:GTRTO

AT+GTWLT

+ACK:GTWLT

AT+GTUPC

+ACK:GTUPC

AT+GTPDS

+ACK:GTPDS

AT+GTLTA

+ACK:GTLTA

AT+GTLTA

+ACK:GTLTA

### ✧ Position Related Report

+RESP:GTFRI

+RESP:GTGEO

+RESP:GTRTL

+RESP:GTPNL

+RESP:GTNMR

+RESP:GTDOG

✧ **Device Power Report**

+RESP:GTPWR

✧ **Device Information Report**

+RESP:GTINF

✧ **Report for Querying**

+RESP:GTALC

+RESP:GTCID

+RESP:GTCSQ

+RESP:GTVER

+RESP:GTALS

✧ **Event Report**

+RESP:GTPNA

+RESP:GTPFA

+RESP:GTBPL

+RESP:GTTEM

+RESP:GTUPC

+RESP:GTLTA

+RESP:GTLTA

✧ **Heartbeat**

+ACK:GTHBD

+SACK:GTHBD

✧ **Server Acknowledgement**

+SACK